

# Index

---

## P

P/R lever .....	98
passengers, no carrying .....	53
pavement, no riding on .....	67
pinging, engine .....	119
plug, spark .....	153
pre-ride inspection .....	55
problems, unexpected .....	204
propeller shaft boots & yoke joint boot .....	181
protective apparel .....	50

## R

rear final gear oil .....	131
recoil starter (Canada only) .....	38, 77
removal,	
rear fender cover .....	117
seat .....	114
tank cover assembly .....	115
reverse,	
assist cable .....	152
assist lever .....	152
gear, shifting into .....	81
indicator .....	14, 17
riding in .....	81
P/R lever .....	41
rider training .....	52
Rider's Club Honda .....	249