


Operation Component Locations

rear cargo rack

seat latch

front cargo rack



rear brake pedal

fuel valve