

# Quick Reference

---

Scheduled Maintenance	Initial: 100 miles (150 km) Regular: every 600 miles (1,000 km)
Pre-ride Inspection	Check the following items each time before you ride (page 67): engine oil, radiator coolant, fuel, tires, drivetrain boots, guards, nuts & bolts, underbody & exhaust system, air cleaner housing drain tube, leaks, loose parts, cables, lights, throttle, brakes, switches, steering.
Fuel/Capacity	unleaded gasoline, pump octane number 86 or higher <b>3.88 US gal (14.7 ℓ)</b> reserve: <b>1.29 US gal (4.9 ℓ)</b>
Engine Oil/ Capacity	API Service Classification SG or higher except oils labeled as energy conserving or resource conserving on the circular API service label, SAE 10W-30, JASO T 903 standard MA, Pro Honda GN4 4-stroke oil or equivalent after draining: <b>3.8 US qt (3.6 ℓ)</b> after draining & oil filter change: <b>4.0 US qt (3.8 ℓ)</b>
Maximum Weight Capacity	<b>573 lb (260 kg)</b> rider, all cargo and accessories