
Controls & Features

(3)

Start Button

LEFT HANDLEBAR



The start button (1) is used for starting the engine. Pushing the button in starts the engine. See Starting Procedure, page 56.

When the start button is pushed, the starter motor will crank the engine. The starter motor will not operate if the engine stop switch is in the OFF (X) position when the start button is pushed.