

F - 12 Front Wheel

HONDA

Ref. No.	Old Part No.	New Part No.	Description	No. Req'd.		No. Used on		News No.
				I	III	From	To	
1	C3105401.1	44701-027-000	RIM, wheel	1	1			
2	C3105401.3	44501-027-000	HUB, wheel	1	1			
3	C3105401.5	44713-027-000	BAND, rim	1	1			
4	C3105401.6	44711-027-000	TIRE, wheel	1	1			
5	C3105401.7	44712-027-000	TUBE, wheel	1	1			
6	C3105401.9	44661-027-000	SPOKE A, front	18	18			
7	C3105401.8	44712-027-000	SPOKE B, front	18	18			
8	C1005407.A	44620-001-010	COLLAR, front axle distance	1	1			
9	C3205429	44301-031-000	AXLE, front wheel	1	1			
10	C3205501A	45100-031-010	PANEL, front brake	1	1			
11	C3105502	45131-027-000	CAM, front brake	1	1			
12	C1005504.A	45120-001-010	SHOE, brake	2	2			
13	C1005506.A	45133-001-010	SPRING, brake shoe	2	2			
14	C3105508.A	45410-027-010	ARM, front brake	1	1			
15	C1005510	45436-001-000	NUT, front brake arm setting	1	1			
16	C1005526	45461-001-000	JOINT, front brake arm	1	1			
17	C1005527	45437-001-000	SPRING, front brake arm	1	1			
18	C1005528	45462-001-000	NUT, front brake adjusting	1	1			
19	C3206441B	44800-031-020	BOX, speedometer gear	1	1			
20	C3206442	44830-031-000	CABLE, speedometer	1	1			
21	C3906442.1	44831-028-000	CABLE, inner speedometer	1	1			
22	C3107769	90306-027-000	NUT, rear fork pivot	1	1			
23	C1007866	90525-001-000	WASHER, brake arm	1	1			
24	C3107942	91252-027-000	OIL SEAL, 23357	1	1			
25	C3207943	91253-031-000	OIL SEAL, 23355	1	1			
26	G86202	96100-62020	BEARING, ball, 6202	2	2			
27	BH-625	92000-06025	BOLT, hex., 6x25	1	1			