

Ref. No.	Part No.	Description	Reqd. No. PC50	No. Used on		News No.
				From	To	
1	11100-063-020	CRANKCASE, right	1	PC50-1000001	PC50-1008607	
● 1-1	11100-063-030	CRANKCASE, right	1	PC50-1008608	8007
2	11201-063-020	CRANKCASE, left	1	PC50-1000001	
3	11191-063-010	PACKING, crankcase	1	PC50-1000001	
4	17133-063-010	CLAMPER, breather tube	1	PC50-1000001	
5	90013-044-000	BOLT, drain plug, 8 mm	1	PC50-1000001	
6	90488-044-000	WASHER, 8 mm	1	PC50-1000001	
7	91211-044-000	OIL-SEAL, 15.25.6	1	PC50-1000001	
8	90704-035-000	PIN, knock, 10×14A	2	PC50-1000001	
9	94301-08100	PIN, dowel, 8×10A	2	
10	94301-08140	PIN, dowel, 8×14A	2	
11	93500-06032	SCREW, pan, 6×32	4	
12	93500-06040	SCREW, pan, 6×40	1	
13	93500-06045	SCREW, pan, 6×45	1	
14	93500-06071	SCREW, pan, 6×71	1	
15	92700-06082	BOLT, stud, 6×82	1	
16	92700-06101	BOLT, stud, 6×101	1	
17	92700-06111	BOLT, stud, 6×111	1	
18	92700-06119	BOLT, stud, 6×119	1	
19	95001-80280-10	TUBE, fuel, 8×280	1	