

Ref. No.	Part No.	Description	Regd. No. PC50	No. Used on		News No.
				From	To	
1	44801-063-000	AXLE, front wheel.....	1	PC50-1000001	
2	45133-044-000	SPRING, brake shoe.....	1	PC50-1000001	
3	45120-063-003	SHOE, brake (Fuji).....	2	PC50-1000001	
4	45410-063-000	ARM, front brake.....	1	PC50-1000001	
5	45131-063-000	CAM, front brake.....	1	PC50-1000001	
6	44806-044-690	GEAR, speedometer.....	1	PC50-1000001	
7	44809-044-000	WASHER, gear box.....	2	PC50-1000001	
8	90751-044-000	OIL-SEAL, 39457.....	1	PC50-1000001	
9	90753-044-000	OIL-SEAL, 451135.....	1	PC50-1000001	
10	90539-044-000	WASHER, speedometer pinion.....	1	PC50-1000001	
11	44805-044-690	PINION, speedometer.....	1	PC50-1000001	
12	45100-063-010	PANEL, front brake.....	1	PC50-1000001	
13	44311-044-020	COLLAR, side, front wheel.....	1	PC50-1000001	
14	90752-044-000	OIL-SEAL, 17326.....	1	PC50-1000001	
15	96100-62010	BEARING, ball, 6201.....	2	
16	44620-044-000	COLLAR, front axle distance.....	1	PC50-1000001	
17	44711-063-003	TIRE, front wheel (Bridgestone).....	1	PC50-1000001	
	44711-063-006	TIRE, front wheel (Nitto).....	1	PC50-1000001	
18	44712-063-000	TUBE, wheel.....	1	PC50-1000001	
19	44713-063-000	FRAP, tire.....	1	PC50-1000001	
20	44701-044-690	RIM, front wheel.....	1	PC50-1000001	
21	44601-063-000	HUB, front wheel.....	1	PC50-1000001	
22	97142-112451	SPORK A, # 13x202-5.....	16	
23	97241-112441	SPORK A, # 13x202.....	16	
24	92000-05022-0A	BOLT, hex., 5x22.....	1	
25	94001-05000-0S	NUT, hex., 5 mm.....	1	
26	94001-10000-0S	NUT, hex., 10 mm.....	1	
27	94101-05000	WASHER, plain, 5 mm.....	1	