


F-8

Front wheel



B168-18-1

Bagian yang diservis Service Item	F.R.T. F.R.T.	Nomor Petunjuk Ref. No.	Nomor Part Part No.	Nama Part Description	Jumlah Regd. No. WIN WIN100	Nomor Serie Serial No.	Catatan Area Code
RIM, RR. WHEEL	2,2	1	42701-030-003	RIM, RR. WHEEL (1.40X17)	(1) -		
TUBE, TIRE	0,8		44701-383-721	RIM, FR. WHEEL (1.40X18)	- 1		
TIRE, FR.		• 2	-	TUBE, TIRE (2.50-17)	(1) -		
AXLE, FR. WHEEL	0,2	•	-	TUBE, TIRE (2.50-18)	- (1)		
HUB, FR. WHEEL	2,6	•	-	TUBE, TIRE (2.75-17)	(1) (1)		Semi Trail
COLLAR, FR. DISTANCE	0,4	• 3	-	FLAP, TIRE (17)	(1) -		
BEARING, RADIAL BALL		•	-	FLAP, TIRE (18)	- 1		
(TAMBAHKAN 0.1 UNTUK MASING-MASING)		• 4	44301-GF6-000	AXLE, FR. WHEEL	(1) (1)		
(ADD 0.1 FOR EACH)		5	44311-GF6-000	COLLAR, FR. WHEEL SIDE	1 1		
		• 6	44601-GB6-921	HUB, FR. WHEEL	(1) (1)		
		7	44605-171-305	SPOKE SET A, 12 x 159,5 (INSIDE)	18 -		
			97282-31181-10	SPOKE SET A, 11x170	- 18		
		8	44606-171-305	SPOKE SET A, 12x159 (OUTSIDE)	18 -		
			97548-31180-10	SPOKE SET A, 11x170	- 18		
		9	44620-GB6-920	COLLAR, FR. DISTANCE	1 1		
		• 10	-	TIRE, FR. (2.50-17-4PR)	(1) -		
		•	-	TIRE, FR. (2.50-18-4PR)	- (1)		
		•	-	TIRE, FR. (2.75-18)	(1) (1)		Semi Trail
		11	90752-035-003	OIL SEAL, 21x35x7	1 1		
		12	6300 RS	BEARING, RADIAL BALL	2 2		