

PART NAME INDEX

Part name	Page	Ref.	Part name	Page	Ref.	Part name	Page	Ref.
[A]								
ADJUSTER, R. CHAIN	68	2	BOLT, BRAKE DISK, 8X24	67	11	BOLT, HEX., 6X20	81	9
	69	4	BOLT, CLUTCH ADJUSTING	34	9	BOLT, KNOCK, 6MM	47	16
ARM ASSY., KICK STARTER	72	2	BOLT, DRAIN PLUG, 12MM	43	9	BOLT, OIL, 10X25	55	15
ARM COMP., CAM CHAIN TENSIONER	81	2	BOLT, FLANGE, 10X110	91	10	BOLT, PIN	63	6
ARM COMP., GEARSHIFT	47	10	BOLT, FLANGE, 10X35	85	7	BOLT, R. HANDLE LEVER PIVOT	54	16
ARM COMP., IN. VALVE ROCKER ..	31	3	BOLT, FLANGE, 10X45	58	11	BOLT, SEALING, 14MM	32	13
ARM COMP., SHIFT DRUM STOPPER ..	47	7	BOLT, FLANGE, 10X48	56	10	BOLT, SEAT HINGE	75	16
ARM, FR. BRAKE	64	10	BOLT, FLANGE, 5X12	30	9	BOLT, SOCKET, 10X25	62	18
ARM, RR. BRAKE	68	6	BOLT, FLANGE, 6MM	78	11	BOLT, SOCKET, 6X14	38	5
ARM, RR. BRAKE STOPPER	84	5		84	9	BOLT, SOCKET, 8MM	62	18
AXLE, FR. WHEEL	65	6	BOLT, FLANGE, 6X10	86	7	BOLT, SOCKET, 8X16	82	10
	67	2	BOLT, FLANGE, 6X100	55	13	BOLT, SOCKET, 8X32	82	11
AXLE, RR. WHEEL	69	6	BOLT, FLANGE, 6X12	46	29	BOLT, SPECIAL FLANGE, 5X8	35	19
	72	4		59	8	BOLT, SPECIAL FLANGE, 6X25	37	11
				74	12	BOLT, SPECIAL, 6X30	75	17
				75	24	BOLT, SPECIAL, 8X40	80	9
				90	12	BOLT, STUD, 7X180.5	43	5
[B]				90	9	BOLT, STUD, 8X18	70	18
BAG, OWNERS MANUAL	76	29	BOLT, FLANGE, 6X14	59	9			
BALL SET, STEEL, #6X23	58	1	BOLT, FLANGE, 6X16	40	5	BOLT, STUD, 8X32	30	15
BALL SET, STEEL, #6X29	58	2		42	6	BOLT, SWINGARM PIVOT	84	6
BAND A, AIR CLEANER CONNECTING TUBE			BOLT, FLANGE, 6X18	79	14	BOOT B	63	8
	78	10		32	19	BOOT COMP.	55	4
BAND B1, WIRE	90	7		43	11	BOX ASSY., SPEEDOMETER GEAR ..	67	7
BAND, WIRE HARNESS	90	11		79	15	BOX, LUGGAGE	75	14
BAR COMP., SIDE STAND	83	5	BOLT, FLANGE, 6X20	37	15	BRACKET SUB ASSY., FR.	63	14
BAR COMP., STEP	82	1		90	14	BRACKET, L. POSITION LIGHT	51	13
BAR, L. PILLION STEP	82	5	BOLT, FLANGE, 6X22	30	17	BRACKET, MUFFLER	84	1
BAR, R. PILLION STEP	82	4		40	6	BRACKET, R. POSITION LIGHT	51	12
BASE COMP., TAILLIGHT	89	5		42	7	BRUSH SET	41	9
BATTERY	75	1		55	21	BULB, HEADLIGHT	51	8
BEARING, NEEDLE, 21X27X18	38	6	BOLT, FLANGE, 6X25	39	8	BULB, POSITION	89	1
BEARING, RADIAL BALL, 6001	46	30		59	10	BULB, POSITION LIGHT	51	7
BEARING, RADIAL BALL, 6200	37	16		81	14	BULB, STOP & TAILLIGHT	89	14
BEARING, RADIAL BALL, 6201	46	31	BOLT, FLANGE, 6X28	64	16	BULB, WEDGE BASE	52	1
BEARING, RADIAL BALL, 6201U ..	66	12	BOLT, FLANGE, 6X30	76	26			
	70	21	BOLT, FLANGE, 6X32	30	10			
	71	21		41	7	BULB, WINKER	87	4
	72	16	BOLT, FLANGE, 6X35	39	9	BULB, WINKER LIGHT	88	6
	73	16		68	19	BUSH A, RUBBER	85	5
BEARING, RADIAL BALL, 6201UU ..	67	13	BOLT, FLANGE, 6X40	34	18	BUSH B, RUBBER	85	3
BEARING, RADIAL BALL, 6203	46	32	BOLT, FLANGE, 6X60	43	12	BUSH, 15MM	45	3
BEARING, RADIAL BALL, 6203U ..	71	23	BOLT, FLANGE, 6X75	43	13	BUSH, GUIDE	61	6
	73	18	BOLT, FLANGE, 6X8	79	13	BUSH, RUBBER UPPER	85	2
BEARING, RADIAL BALL, 6301U ..	71	22	BOLT, FLANGE, 8X12	84	18			
	73	17	BOLT, FLANGE, 8X14	76	25	[C]		
BEARING, RADIAL BALL, 63/22 ..	44	7	BOLT, FLANGE, 8X18	82	14	CABLE ASSY., SPEEDOMETER	52	14
BODY COMP., FRAME	91	4	BOLT, FLANGE, 8X20	80	13	CABLE COMP., FR. BRAKE	54	10
BODY SET, COCK	49	25	BOLT, FLANGE, 8X25	32	20	CABLE COMP., THROTTLE	54	1
BOLT-WASHER, 6X12	30	16		63	15	CALIPER SUB ASSY., R. FR.	63	13
	86	12	BOLT, FLANGE, 8X32	91	9	CAMSHAFT COMP.	31	2
BOLT-WASHER, 8X22	32	14	BOLT, FR. FORK	61	10	CAM, FR. BRAKE	64	8
BOLT A, BRAKE STOPPER	68	15	BOLT, FR. HANDLE COVER	56	11	CAM, RR. BRAKE	68	5
BOLT A, STOPPER ARM	84	12	BOLT, HANDLE LEVER PIVOT	55	14	CAP ASSY., NOISE SUPPRESSOR ..	90	4
BOLT, ADAPTER, 10MM	53	4	BOLT, HEAD COVER	29	3	CAP, A.C. GENERATOR	39	5
BOLT, ADJUSTING	51	10	BOLT, HEX., 6X10	46	28	CAP, BLEEDER	63	4
BOLT, BODY COVER SETTING	80	10	BOLT, HEX., 6X14	43	10			