

PART NAME INDEX

Part name	Page	Ref.	Part name	Page	Ref.	Part name	Page	Ref.
CAP, CABLE SEALING	49	19	COLLAR, FR. WHEEL SIDE	65	7	DIAPHRAGM.....	55	9
CAP, CHANGE SWITCH CONTACT ...	47	14	COLLAR, KICK SPRING	67	3	DISK, CLUTCH FRICTION.....	37	6
CAP, FR. FORK	61	11	COLLAR, LOCK PLATE	48	5	DISK, FR. BRAKE.....	67	10
CAP, FUEL FILLER	74	3	COLLAR, MAIN SIDE COVER.....	59	13	DOWEL PIN, 10X14.....	43	7
CAP, LOCK NUT	53	1	COLLAR, MAIN SIDE COVER.....	59	7	DOWEL PIN, 8X14.....	34	17
CAP, MASTER CYLINDER	55	7	COLLAR, MUFFLER MOUNTING.....	80	7	DOWEL PIN, SPECIAL, 8X14.....	39	7
CAP, RR. CARRIER	75	13	COLLAR, RR. AXLE DISTANCE	69	10		29	5
CARBURETOR ASSY.....	49	17		72	8		30	13
CASE COMP., L. FR. BOTTOM	62	17	COLLAR, RR. BRAKE PANEL SIDE ..	68	3	DRIVER, SCREW.....	33	3
CASE COMP., R. FR. BOTTOM	61	7	COLLAR, RR. WHEEL SIDE	69	8	DRUM, GEARSHIFT.....	94	1
CASE SUB ASSY., AIR CLEANER ..	78	5		72	6	DUST SEAL, 21X37X7	47	4
CASE, DRIVE CHAIN	84	2	COLLAR, RUBBER BUSH	85	4	DUST SEAL, 27X40X4.5.....	66	13
CASE, L. FR. BOTTOM	62	17	COLLAR, RUBBER BUSH UPPER	85	4		71	14
CASE, L. FR. FORK	62	17	COLLAR, WINKER STAY	80	8	DUST SEAL, 42X54X7.....	73	24
CASE, R. FR. BOTTOM	61	7	CONTACT ASSY., CHANGE SWITCH ..	43	4	DUST SEAL, 42X54X7.....	67	19
CASE, R. FR. FORK	61	7	COTTER, VALVE.....	31	10	DUST SEAL, BRAKE CAM.....	64	7
CATCH COMP., SEAT	75	9	COUNTERSHAFT	45	2	DUST SEAL, STEERING HEAD.....	68	9
CENTER, CLUTCH	37	5	COVER COMP., CYLINDER HEAD	29	1		58	8
CHAIN, DRIVE	84	3	COVER COMP., HANDLE	89	11			
CHAIN, CAM	32	2	COVER COMP., LICENSE	56	7			
CHAMBER SET, FLOAT	49	5	COVER COMP., L. RR. CRANKCASE ..	34	2			
CIRCLIP, 17MM	46	26	COVER COMP., R. CRANKCASE	34	1			
CIRCLIP, 20MM	45	25	COVER SET, FR. TOP	92	1			
	46	25	COVER SET, L. BODY	77	6			
CIRCLIP, 7MM	36	27	COVER SET, L. MAIN PIPE SIDE ..	92	7			
CIRCLIP, EXTERNAL, 16MM	48	11	COVER SET, R. BODY	77	5			
CIRCLIP, INTERNAL, 18.8	55	17	COVER SET, R. MAIN PIPE SIDE ..	92	6			
CIRCLIP, INTERNAL, 45MM	36	25	COVER SET, TAIL	77	7			
CLAMPER B, BRAKE HOSE	55	3	COVER SUB ASSY., AIR CLEANER ..	78	8	FENDER A, FR.....	59	3
CLAMPER, BRAKE HOSE	59	1	COVER, BATTERY	75	3	FENDER B, FR.....	59	4
CLAMPER, OVER FLOW	39	4	COVER, CENTER	77	1	FENDER, RR.....	86	3
	52	8	COVER, FR. HANDLE	56	6	FILTER COMP., AIR.....	79	2
CLAMP, CORD	78	14	COVER, L. BODY LOWER	77	4	FLANGE SUB ASSY., FINAL DRIVEN	69	9
CLAMP, TUBE	79	10	COVER, L. CRANKCASE	39	1		72	7
CLIP, FUEL HOSE	47	3	COVER, MAIN PIPE	92	4	FLAP, TIRE.....	65	5
CLIP, GEARSHIFT FORK GUIDE PIN	51	9	COVER, MUFFLER	80	5		70	17
CLIP, HEADLIGHT	51	9	COVER, OIL FILTER	35	1	FLOAT SET.....	49	3
CLIP, HIGH TENSION CORD & SENSOR CORD	34	11	COVER, RR. LICENSE LIGHT	89	15	FLYWHEEL COMP.....	40	1
CLIP, OIL DRAIN TUBE	79	1	COVER, RUBBER	51	2	FORK ASSY., L. FR.....	61	16
CLIP, PISTON PIN, 13MM	34	3	COVER, R. BODY LOWER	77	3		62	16
	44	5	COVER, SEAT LOCK	86	4	FORK ASSY., R. FR.....	60	1
CLIP, TUBE	74	26	CRANKCASE COMP., L.	43	2	FORK, GEARSHIFT.....	47	1
	75	22	CRANKCASE COMP., R.	43	1	FUEL UNIT.....	74	6
	78	15	CRANKSHAFT COMP.	44	1	FUSE, MINI.....	76	27
	79	11	CUP, FUEL STRAINER	49	23		90	28
CLIP, VALVE GUIDE	30	3	CUSHION ASSY., RR.....	85	1		15	15
CLUTCH ASSY., ONE WAY	38	2	CUSHION, C.D.I. UNIT	90	1		16	16
COIL ASSY., IGNITION	90	3	CYLINDER COMP.	33	1			
COLLAR A, HANDLE SETTING	57	14	CYLINDER COMP., FR. MASTER	55	11			
COLLAR B, HANDLE SETTING	57	15	CYLINDER SET, MASTER	55	23			
COLLAR, 19.1X30X4	35	18	CYLINDER SUB ASSY., FR. BRAKE			GASKET SET.....	49	1
COLLAR, 6.2X20	75	18		55	5		79	11
COLLAR, CAM CHAIN TENSIONER ..	32	5	C.D.I. UNIT.....	90	22	GASKET, AIR FEED PIPE.....	30	6
COLLAR, CLUTCH OUTER	37	4				GASKET, CARBURETOR INSULATOR ..	33	5
COLLAR, FR. AXLE DISTANCE	65	8				GASKET, CYLINDER.....	30	2
	67	4				GASKET, CYLINDER HEAD.....	80	4
	59	5				GASKET, EX. PIPE.....	49	1
						GASKET, FLOAT CHAMBER.....	29	21
						GASKET, HEAD COVER.....	29	2
						GASKET, L. CRANKCASE COVER.....	39	3