


F - 4 Fr. Brake Master Cylinder



Service item	F.R.T.	No.	Part Number	Description	QTY	Notes
1 SWITCH, FRONT STOP	0.2	1	17910-KYT-941	CABLE COMP., THROTTLE	1	
SWITCH, STOP :BOTH	0.7	2	30158-GW3-980	E-RING, 3MM	1	
2 HOSE, FRONT BRAKE	0.6	3	35160-KWW-A01	SWITCH UNIT, STARTER	1	
.INCLUDES: Bleed brakes			35160-KWW-B21	SWITCH UNIT, STARTER	1	
			35160-KWW-711	SWITCH UNIT, STARTER	1	
6 CYLINDER, FRONT BRAKE MASTER	0.7	4	35162-KYT-902ZE	HOUSING, STARTER SWITCH RR.		
.INCLUDES: Bleed brakes				*NH167MU* IRON NAIL SILVER METALLIC-U	1	
10 DIAPHRAGM, FRONT BRAKE		5	35165-KYT-941ZA	HOUSING COMP., STARTER SWITCH		
MASTER CYLINDER	0.1			*NH167MU* IRON NAIL SILVER METALLIC-U	1	
12 PISTON SET, FRONT BRAKE MASTER	0.7	6	35170-KWW-A02	SWITCH UNIT, DIMMER	1	
.INCLUDES: Bleed brakes			35170-KWW-B22	SWITCH UNIT, DIMMER	1	
13 LEVER, HANDLE :RIGHT	0.1		35170-KWW-602	SWITCH UNIT, DIMMER	1	
LEVER, HANDLE :BOTH	0.3	7	35180-KWW-A01	SWITCH UNIT, HORN	1	
			35180-KWW-B21	SWITCH UNIT, HORN	1	
			35180-KWW-601	SWITCH UNIT, HORN	1	
		8	35200-KWW-A01	SWITCH UNIT, WINKER	1	
			35200-KWW-B21	SWITCH UNIT, WINKER	1	
			35200-KWW-601	SWITCH UNIT, WINKER	1	
		9	35202-KYT-902ZE	HOUSING, WINKER SWITCH RR.		
				NH167MU IRON NAIL SILVER METALLIC-U	1	
		10	35205-KYT-902ZE	HOUSING COMP., WINKER SWITCH		
				NH167MU IRON NAIL SILVER METALLIC-U	1	
		11	35340-KYT-901	SWITCH ASSY., RR. STOP	1	
		12	43450-KYT-900	CABLE COMP., RR. BRAKE	1	