



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1		(5,7,9) MAINSHAFT, TRANSMISSION	4.1
		.INCLUDES: Engine removal and installation	
2		210141A .Replace countershaft add	0.2
2		(4,6,8,10,15) COUNTERSHAFT, TRANSMISSION ...	4.1
		.INCLUDES: Engine removal and installation	
		210142A .Replace mainshaft add	0.2
11		213135 SPROCKET, DRIVE	0.2
28		2101C2 BEARING, MAINSHAFT :LEFT	4.1
		.INCLUDES: Engine removal and installation	
29		2101C8 BEARING, COUNTERSHAFT :RIGHT ..	4.8
		.INCLUDES: Engine removal and installation	
30		2101C5 BEARING, MAINSHAFT :RIGHT	4.8
		.INCLUDES: Engine removal and installation	
		2101C6 BEARING, MAINSHAFT :BOTH	5.0
		.INCLUDES: Engine removal and installation	
+		2101C7 BEARING, COUNTERSHAFT :LEFT ..	4.1

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			ANF125MWH F		
1	23211-KPH-C00	MAINSHAFT(14T)	1		
2	23221-KPH-C00	COUNTERSHAFT	1		
3	23415-KPH-C00	BUSH, 15MM	1		
4	23421-KPH-C00	GEAR, COUNTERSHAFT FIRST(35T) ..	1		
5	23431-KPH-C00	GEAR, MAINSHAFT SECOND(20T) ..	1		
6	23441-KPH-C00	GEAR, COUNTERSHAFT SECOND(31T)	1		
7	23451-KPH-C00	GEAR, MAINSHAFT THIRD(20T) ..	1		
8	23461-KPH-C00	GEAR, COUNTERSHAFT THIRD(23T)	1		
9	23471-KPH-C00	GEAR, MAINSHAFT FOURTH(26T) ..	1		
10	23481-KPH-C00	GEAR, COUNTERSHAFT FOURTH(24T)	1		
11	23801-KVR-C00	SPROCKET, DRIVE(14T)	1		
12	23802-KVR-C00	PLATE, FIXING	1		
13	23911-KPH-C00	COLLAR, LOCK PLATE	1		
14	24305-KPH-C00	SPRING, CHANGE FRICTION	1		
15	24306-KPH-C00	PLATE, DRUM LOCK	1		
16	90412-KPH-C00	WASHER, SPECIAL, 12X23	1		
17	90413-KPH-C00	WASHER, THRUST, 15MM	1		
18	90441-KRM-840	PLATE, BEARING HOLDER	2		
19	90452-KPH-C00	WASHER, SPECIAL, 12MM	1		
20	90453-KPH-C00	WASHER, THRUST, 20MM	1		
21	90461-KPH-C00	WASHER, SPLINE, 17MM	2		
22	90463-KPH-C00	WASHER, SPLINE, 20X1.2	2		
23	90601-KVR-C00	CIRCLIP, 17MM	2		
24	90604-KVR-C00	SET RING, 20MM	2		
25	91204-KPH-901	OIL SEAL, 17X30X5	1		