

PART NAME INDEX

J 2

Part name	Address	Page	Ref.	Part name	Address	Page	Ref.	Part name	Address	Page	Ref.
CLAMPER, BRAKE HOSE	F4	49	4	COVER, OIL FILTER	D7	31	1	FUEL UNIT	F14	59	7
CLAMPER, OVER FLOW	D1	25	14	COVER, RR. HANDLE	F5	50	10	FUSE B	G12	73	14
	D10	34	4	COVER, STARTER MOTOR TERMINAL	G13	74	8				15
CLAMP B, TUBE	D14	38	8	COVER, TAIL	F16	61	6		G13	74	21
CLAMP, TUBE	G1	62	13	COVER, TAPPET ADJUSTING HOLE	D1	25	7				22
	G2	63	11	COWL, L. UNDER	G16	77	3	[G]			
CLIP, 7MM	D6	30	16	COWL, R. UNDER	G16	77	2	GARNISH, L. FR. TOP COVER	H1	78	13
CLIP, FUEL HOSE	G2	63	12	CRANKCASE COMP., L.	D14	38	3	GARNISH, L. HANDLE FR.	F5	50	12
CLIP, OIL DRAIN TUBE	G2	63	1	CRANKCASE COMP., R.	D14	38	1	GARNISH, L. RR.	F16	61	5
CLIP, PISTON PIN	D15	39	5	CRANKSHAFT COMP.	D15	39	1	GARNISH, R. FR. TOP COVER	H1	78	11
CLIP, TUBE	E5	45	29	CUP, FUEL STRAINER	E4	44	19	GARNISH, R. HANDLE FR.	F5	50	11
	F14	59	10	CUSHION ASSY., RR.	G8	69	1	GARNISH, R. RR.	F16	61	4
	G1	62	14	CUSHION, BATTERY	G12	73	9	GASKET SET	E4	44	1
	G2	63	13	CUSHION, C.D.I. UNIT	G13	74	1	GASKET SET B	E4	44	10
CLIP, VALVE GUIDE	D1	25	2	CUSHION, FR. TOP COVER	H1	78	12	GASKET, AIR FEED PIPE	G2	63	6
CLUTCH ASSY., ONE WAY	D12	36	2	CYLINDER COMP.	D5	29	1	GASKET, CARBURETOR INSULATOR	D1	25	11
COIL ASSY., IGNITION	G13	74	3	CYLINDER SET, MASTER	F4	49	12	GASKET, CYLINDER	D5	29	2
COLLAR A, HANDLE SETTING	F6	51	19	CYLINDER SUB ASSY., FR. BRAKE	F4	49	7	GASKET, CYLINDER HEAD	D1	25	5
COLLAR B, HANDLE SETTING	F6	51	20		MASTER	F4	49	GASKET, EX. PIPE	G3	64	1
COLLAR, 6.2X20	G12	73	10	C.D.I. UNIT	G13	74	2	GASKET, FLOAT CHAMBER	E4	44	17
COLLAR, CLUTCH OUTER	D8	32	3					GASKET, L. CRANKCASE COVER	D10	34	3
COLLAR, FR. AXLE DISTANCE	F11	56	3	[D]				GASKET, L. CYLINDER HEAD SIDE			
COLLAR, FR. FENDER	F8	53	4	DAMPER SET, WHEEL	F13	58	1	COVER	D1	25	8
COLLAR, FR. WHEEL SIDE	F11	56	2	DIAPHRAGM	F4	49	10	GASKET, OIL FILTER	D7	31	2
COLLAR, HORN SETTING	G13	74	11	DISK, CLUTCH FRICTION	D8	32	5	GASKET, R. CRANKCASE COVER	D6	30	3
COLLAR, KICK RETAINER	E3	43	5	DISK, FR. BRAKE	F11	56	11	GASKET, TENSIONER LIFTER	D4	28	6
COLLAR, KICK SPRING	E3	43	8	DOWEL PIN, 10X12	D5	29	6	GAUGE, OIL LEVEL	D6	30	4
COLLAR, LICENSE LIGHT	G9	70	10		D14	38	18	GEAR COMP., PRIMARY DRIVE	D7	31	13
COLLAR, LOCK PLATE	D16	40	13	DOWEL PIN, 3X5	D15	39	8	GEAR COMP., STARTER DRIVEN	D12	36	1
COLLAR, MAIN SIDE COVER	F8	53	6	DOWEL PIN, SPECIAL, 8X12	D3	27	15	GEAR, COUNTERSHAFT FIRST	D16	40	4
COLLAR, MAIN STEP MOUNTING	G5	66	5		D6	30	17	GEAR, COUNTERSHAFT FOURTH	D16	40	10
COLLAR, MUFFLER MOUNTING	G5	66	2	DRIVER, SCREW	G15	76	1	GEAR, COUNTERSHAFT SECOND	D16	40	6
COLLAR, RR. AXLE DISTANCE	F13	58	8	DRUM, GEARSHIFT	E2	42	4	GEAR, COUNTERSHAFT THIRD	D16	40	8
COLLAR, RR. BRAKE PANEL SIDE	F12	57	3	DUST SEAL, 40X50X5	F11	56	15	GEAR, MAINSHAFT FOURTH	D16	40	9
COLLAR, RR. FENDER	H1	78	22	DUST SEAL, BRAKE CAM	F12	57	9	GEAR, MAINSHAFT SECOND	D16	40	5
COLLAR, RR. WHEEL SIDE	F13	58	6	DUST SEAL, STEERING HEAD	F7	52	8	GEAR, MAINSHAFT THIRD	D16	40	7
COLLAR, STARTER REDUCTION	D12	36	5	[E]				GEAR, OIL PUMP DRIVE	D15	39	6
COLLAR, WINKER STAY	G3	64	5	ELEMENT COMP., AIR CLEANER	G1	62	1	GEAR, OIL PUMP DRIVEN	D9	33	2
CONTACT ASSY., CHANGE SWITCH	D14	38	9	EMBLEM, PRODUCT	F2	47	9	GEAR, SPEEDOMETER	F11	56	9
COTTER, VALVE	D3	27	12	E-RING, 6MM	D9	33	6	GEAR, STARTER REDUCTION	D12	36	3
COUNTERSHAFT	D16	40	2	[F]				GRIP	G15	76	2
COVER COMP., LICENSE	G9	70	4	FENDER A, FR.	F8	53	2	GRIP COMP., THROTTLE	F3	48	5
COVER COMP., L. RR.	D10	34	2	FENDER B, FR.	F8	53	3	GRIP, L. HANDLE	F3	48	6
COVER COMP., R. CRANKCASE	D6	30	1	FENDER, RR.	G9	70	7	GROMMET, SIDE COVER	F5	50	14
COVER SET, FR. HANDLE	F5	50	13	FILTER COMP., AIR	G2	63	2	GUIDE COMP., CAM CHAIN	D4	28	7
COVER SET, L. BODY	F16	61	3	FLANGE SUB ASSY., FINAL DRIVEN	F13	58	7	GUIDE, CLUTCH OUTER	D8	32	2
COVER SET, L. MAIN PIPE SIDE	G16	77	4	FLOAT SET	E4	44	3	GUIDE, FR. BRAKE CABLE	F8	53	1
COVER SET, R. BODY	F16	61	2	FLYWHEEL COMP.	D11	35	1	GUIDE, IN. VALVE	D1	25	4
COVER SET, R. MAIN PIPE SIDE	G16	77	1	FORK ASSY., L. FR.	F9	54	11	[H]			
COVER SUB ASSY., AIR CLEANER	G1	62	6	FORK ASSY., R. FR.	F9	54	1	HARNES, WIRE	G13	74	7
COVER, BATTERY	G12	73	4	FORK, L. GEARSHIFT	E2	42	2	HEADLIGHT UNIT	F1	46	3
COVER, CENTER	G16	77	9	FORK, L. GEARSHIFT	E2	42	1	HEAD COMP., CYLINDER	D1	25	1
	H1	78	15	FORK, R. GEARSHIFT	E2	42	1	HINGE, SEAT	F15	60	3
COVER, FR. TOP	G16	77	10					HOLDER, DRUM STOPPER	E2	42	6
COVER, LUGGAGE INNER	G12	73	7					HOLDER, L. PILLION STEP	G5	66	13
COVER, L. CRANKCASE	D10	34	1								
COVER, L. CYLINDER HEAD SIDE	D1	25	6								
COVER, MAIN PIPE UPPER	G16	77	7								
COVER, MUFFLER	G3	64	4								

