

PART NAME INDEX

J 4

Part name	Address	Page	Ref.	Part name	Address	Page	Ref.	Part name	Address	Page	Ref.
PLATE, DIAPHRAGM	F4	49	11	RUBBER, SEAL	F15	60	14	SEAT ASSY., DOUBLE	F15	60	2
PLATE, DRUM LOCK	D16	40	15	RUBBER, SEAT LOCK	H1	78	14	SEAT, VALVE SPRING	D3	27	11
PLATE, FIXING	D16	40	12	RUBBER, STAND STOPPER	G6	67	4	SEAT, VALVE SPRING OUTER	D3	27	10
PLATE, PILLION STEP	G5	66	9	RUBBER, STEP	G5	66	7	SET RING, 20MM	D16	40	24
PLATE, STOPPER	D1	25	3	RUBBER, STOPPER ARM	F12	57	8		E3	43	11
PLATE, TENSIONER SETTING	D4	28	4	RUBBER, TAILLIGHT BRACKET	G13	74	9	SET RING, 25MM	D7	31	23
PLUG, BEARING PUSH	D14	38	4					SHAFT, EX. ROCKER ARM	D3	27	5
PLUG, SPARK	D1	25	15	[S]				SHAFT, GEARSHIFT FORK	E2	42	3
PLUNGER, CAM SETTING	D1	25	9	SCREEN, FUEL STRAINER	E4	44	20	SHAFT, IN. ROCKER ARM	D3	27	4
PROTECTOR	F4	49	8	SCREEN, OIL FILTER	D9	33	5	SHAFT, REDUCTION GEAR	D12	36	4
PROTECTOR COMP., R. COVER	D6	30	2	SCREW-WASHER, 3X12	E4	44	25	SHAFT, RR. BRAKE PIVOT	G6	67	2
PUMP ASSY., OIL	D9	33	1	SCREW-WASHER, 3X22	F2	47	6	SHOE SET, BRAKE	F12	57	1
				SCREW-WASHER, 4X10	E5	45	26	SLEEVE, RR. WHEEL	F13	58	5
[R]				SCREW-WASHER, 4X12	F4	49	20	SOCKET COMP.	F2	47	5
RACE, STEERING BOTTOM BALL ...	F7	52	4	SCREW-WASHER, 4X12	F4	49	20	SOCKET COMP., HEADLIGHT	F1	46	4
RACE, STEERING BOTTOM CONE ...	F7	52	7	SCREW-WASHER, 4X14	E5	45	27	SOCKET COMP., L. FR. WINKER ...	G10	71	5
RACE, STEERING TOP BALL	F7	52	3	SCREW-WASHER, 5X10	E5	45	28	SOCKET COMP., R. FR. WINKER ...	G10	71	3
RACE, STEERING TOP CONE	F7	52	6	SCREW SET	E4	44	5	SPANNER, 10X12	G15	76	4
RAIL, RR. GRAB	F15	60	8					SPANNER, 14X17	G15	76	5
RATCHET, STARTER DRIVE	E3	43	2	SCREW, 6X12	H1	78	20	SPEEDOMETER ASSY.	F2	47	3
RECTIFIER COMP., REGULATOR ...	G13	74	6	SCREW, BLEEDER	F10	55	3	SPEEDOMETER COMP.	F2	47	4
REFLECTOR, RR. REFLEX	G9	70	6	SCREW, FLAT, 4X12	F4	49	19	SPINDLE COMP., GEARSHIFT	E2	42	9
RELAY COMP., STARTER	G13	74	14	SCREW, OVAL, 5X16	F2	47	11	SPINDLE, KICK STARTER	E3	43	3
RELAY COMP., WINKER	G13	74	12	SCREW, OVAL, 6X65	F6	51	16	SPRING ASSY., RR. BRAKE RETURN	G4	65	8
RETAINER COMP., BALL	D6	30	12	SCREW, PAN, 5X11.5	F6	51	21	SPRING A, BRAKE ROD	G4	65	14
RETAINER, FUEL UNIT	F14	59	9		F16	61	8	SPRING A, MAIN STAND	G6	67	9
RETAINER, GEAR BOX	F11	56	5	SCREW, PAN, 5X12	G12	73	12	SPRING A, SIDE STAND	G6	67	10
RETAINER, KICK SPRING	E3	43	4	SCREW, PAN, 5X20	G13	74	17	SPRING, BEARING PUSH	D14	38	5
RETAINER, SPRING	D7	31	15	SCREW, PAN, 5X25	F3	48	16	SPRING, BRAKE	D6	30	11
RETAINER, VALVE SPRING	D3	27	9		F3	48	16	SPRING, BRAKE SHOE	F12	57	6
RING SET, PISTON	D15	39	2	SCREW, PAN, 6X6	G1	62	11	SPRING, CAM PLATE SIDE	D6	30	7
RING, HANDLE WEIGHT SNAP	F5	50	9	SCREW, PAN, 6X6	D4	28	8	SPRING, CHANGE FRICTION	D16	40	14
RING, OIL SEAL STOPPER	F9	54	8	SCREW, SIDE STAND PIVOT	G6	67	6	SPRING, CHANGE SWITCH CONTACT	E2	42	15
RING, PISTON	F9	54	7	SCREW, SPECIAL, 5MM	H1	78	17	SPRING, CLUTCH	D8	32	9
RING, STOPPER	F10	55	6					SPRING, FR. FORK	F9	54	2
ROD COMP., RR. BRAKE	G4	65	6	SCREW, TAPPET ADJUSTING	D3	27	13	SPRING, GEARSHIFT ARM	E2	42	11
ROLLER, 3X8.5	E2	42	18	SCREW, TAPPING, 3X16	F2	47	12	SPRING, GEARSHIFT RETURN	E2	42	12
ROLLER, 4X10.8	E2	42	19	SCREW, TAPPING, 4X12	F1	46	9	SPRING, KICK RETURN	E3	43	7
ROLLER, 4X24	D9	33	8		F6	51	22	SPRING, LOCK KEY SETTING	F15	60	1
ROLLER, 5X8	D7	31	25		F16	61	10	SPRING, ONE WAY RETAINER	D7	31	4
ROTOR, OIL PUMP INNER	D9	33	3					SPRING, PAD	F10	55	5
ROTOR, OIL PUMP OUTER	D9	33	4					SPRING, PLUNGER	D1	25	10
RUBBER A, HANDLE WEIGHT	F5	50	8					SPRING, PRIMARY CLUTCH	D7	31	6
RUBBER A, INSERT	D5	29	3					SPRING, REBOUND	F9	54	4
RUBBER A, TAILLIGHT MOUNTING	G11	72	3					SPRING, SEAT LOCK	F15	60	5
RUBBER B, INSERT	D5	29	4	SCREW, TAPPING, 4X16	H1	78	24	SPRING, SHIFT DRUM STOPPER ...	E2	42	8
RUBBER B, SEAT SETTING	F15	60	15		G9	70	12	SPRING, SIDE FRICTION	D7	31	8
RUBBER C, INSERT	D5	29	5		G10	71	12	SPRING, STARTER PINION			
RUBBER, BODY COVER MOUNTING ..	F16	61	1		H1	78	25	FRICTION	E3	43	6
RUBBER, CHANGE PEDAL	G4	65	13	SCREW, TAPPING, 4.2X13	G11	72	6	SPRING, STOP SWITCH	G4	65	5
RUBBER, CLUTCH DAMPER	D7	31	12	SCREW, TAPPING, 4.2X16	G9	70	2	SPRING, SUB GEAR	D7	31	16
RUBBER, KEY CYLINDER	G16	77	8	SCREW, TAPPING, 5X16	F2	47	13	SPRING, VALVE	D3	27	8
RUBBER, KICK STARTER	G4	65	3	SCREW, TAPPING, 5X25	G1	62	12	SPROCKET, CAM	D4	28	1
RUBBER, LUGGAGE BOX MOUNTING	G12	73	8	SCREW, U-LOCK FLAT, 6X12	G14	75	6	SPROCKET, DRIVE	D16	40	11
RUBBER, MAIN STEP MOUNTING	G5	66	6	SEAL SET, FR. FORK	F9	54	10	SPROCKET, FINAL DRIVEN	F13	58	3
RUBBER, MUFFLER MOUNTING	G5	66	1	SEAL SET, PISTON	F10	55	1	STAND COMP., MAIN	G6	67	1
RUBBER, PILLION STEP	G5	66	8	SEAL, AIR CLEANER COVER	G1	62	2	STATOR COMP.	D11	35	2
RUBBER, PROTECTOR MOUNTING ...	G3	64	2	SEAL, DUST	F9	54	6	STAY, AIR SUCTION VALVE	G2	63	4
				SEAL, VALVE STEM	D3	27	1	STAY, FR. TOP COVER	G14	75	5

