


E-4 Left crankcase cover · A.C. generator

E-4 Left crankcase cover · A.C. generator



Ref. No.	Part No.	Description	Repl. No.		Serial No.
			CL	CL	
1	11341-324-000	COVER COMP., L. CRANKCASE	1	1	
2	11361-107-000	COVER, L. CRANKCASE RR.	1	1	
3	11431-110-730	COVER, DYNAMO	1	1	
4	31100-331-673	GENERATOR ASSY., A.C. (KOKUSAN)	1	1	
	31100-331-674	GENERATOR ASSY., A.C. (ND)	1	1	
5	31101-107-013	ROTOR COMP. (KOKUSAN)	1	1	
	31101-107-014	ROTOR COMP. (ND)	1	1	
6	31102-331-673	STATOR COMP. (KOKUSAN)	1	1	
	31102-331-674	STATOR COMP. (ND)	1	1	
7	31104-028-060	BOLT, ROTOR SETTING	1	1	
8	31105-028-000	WASHER, ROTOR SETTING	1	1	
9	32971-107-000	GROMMET, A.C. GENERATOR CORD	1	1	
10	32976-107-000	CLAMPER, WIRE HARNESS	1	1	
11	35750-001-020	CONTACT ASSY., NEUTRAL SWITCH	1	1	
12	35752-028-300	SPACER, NEUTRAL SWITCH	1	1	
13	91302-107-010	GASKET, L. CRANKCASE COVER	1	1	
	91302-355-000				
14	91309-302-000	O-RING, 70X2.4	1	1	
15	91312-107-000	O-RING, 7X1.7	1	1	
16	93500-06012	SCREW, PAN, 6X12	1	1	
17	93500-06032	SCREW, PAN, 6X32	9	9	
18	93700-05016-08	SCREW, DVAL, 5X16	2	2	