


F-15 Brake pedal · Step · Side stand

K 1

F-15 Brake pedal · Step · Side stand



Ref. No.	Part No.	Description	Reqd. No. CL. CL. 1255 1255	Serial No.
1	24700-107-700	PEDAL COMP., GEAR CHANGE	1 1	
2	28300-331-671	ARM ASSY., KICK STARTER	1 1	
3	28301-331-671	ARM, KICK STARTER	1 1	
4	28301-001-000	PEDAL, KICK STARTER	1 1	
5	28303-001-000	WASHER, KICK STARTER KNUCKLE	1 1	
6	28311-001-000	RUBBER, KICK STARTER	1	
	95011-51000	RUBBER A, KICK STARTER	1 1	
7	28322-001-000	SPRING, KICK STARTER KNUCKLE	1 1	
8	28324-001-000	CLIP, KICK STARTER KNUCKLE	1 1	
9	35350-272-003	SWITCH ASSY., STOP (TOYD)	1 1	
10	35357-107-010	SPRING, STOP SWITCH	1 1	
11	43450-041-000	ROD, RR, BRAKE	1 1	
12	43472-001-000	SPRING, RR, BRAKE ROD	1	
	95014-73100	SPRING A, BRAKE ROD	1 1	
13	45461-071-000	JOINT, FR, BRAKE ARM	1	
	95015-31000	JOINT A, BRAKE ARM	1 1	
14	45462-078-000	NUT, FR, BRAKE ADJUSTING	1	
	95015-41000	NUT A, BRAKE ROD ADJUST	1 1	
15	46500-108-000	PEDAL COMP., BRAKE	1 1	
16	46514-107-010	SPRING, BRAKE PEDAL	1 1	
17	50526-028-010	PIPE, MAIN STAND PIVOT	1 1	
18	50530-107-7008	BAR COMP., SIDE STAND	1 1	
19	50542-746-750	SPRING, SIDE STAND	1	
	95014-72101	SPRING A, SIDE STAND	1 1	
20	50603-033-000	PIN, STEP BAR JOINT	2 2	
21	50610-108-6708	BAR COMP., STEP	1 1	
22	50616-056-670	ARM COMP., R. STEP	1 1	
23	50617-056-670	SPRING, R. STEP RETURN	1 1	
24	50642-283-0208	ARM COMP., L. STEP	1 1	
25	50644-283-000	SPRING, L. STEP RETURN	1 1	