


F-19 Wire harness - Battery

**K 6**

F-19 Wire harness - Battery



Ref. No.	Part No.	Description	Req. No.		Serial No.
			CL	CL	
1	17247-240-000	GROMMET A; AIR CLEANER CASE	1	1	
2	30250-330-003	CONDENSER ASSY.	1	2	
3	30400-330-003	COIL COMP.; IGNITION	1	1	
4	30507-107-000	COLLAR; IGNITION COIL SETTING	2	2	
5	30700-259-810	CAP. ASSY.; NOISE SUPPRESSOR	1	1	
6	31468-107-000	COVER; BATTERY TERMINAL	1	1	
7	31500-110-671	BATTERY ASSY.	1	1	
8	31700-102-731	RECTIFIR ASSY.		1	
9	31701-107-701	RECTIFIER COMP.; SELENIUM	1		
10	31706-364-670	CLIP; BATTERY DRAIN PIPE		1	
11	31707-107-780	STAY; SELENIUM RECTIFIER	1		
12	32100-107-781	HARNES; WIR	1		
13	32100-359-700	HARNES; WIRE		1	
14	32111-230-000	CASE; FUSE CONNECTOR	1	1	
15	32113-107-000	HOLDER; FUSE	1	1	
16	35030-111-971	SWITCH KIT; MAIN	1	1	
17	35100-111-671	SWITCH ASSY.; COMBINATION	1	1	
18	38100-110-671	HORN ASSY.	1	1	
19	38303-107-670	SUB CORD; WINNER RELAY	1	1	
20	38306-092-670	SUSPENSION; WINNER RELAY	1	1	
21	50375-331-000	BRACKET; MAIN SWITCH	1	1	
22	83601-307-000	BAND; BATTERY	1		
	95012-15000	BAND O; BATTERY	1	1	
23	84705-292-000	RUBBER; NUMBER BRACKET CUSHION	2	2	
24	84704-286-000	COLLAR; NUMBER BRACKET SETTING	2	2	
25	90122-107-000	BOLT; BATTERY TERMINAL	2	2	
26	90306-107-000	NUT; BATTERY TERMINAL	2	2	
27	90501-107-000	WASHER; BATTERY TERMINAL	2	2	
28	90525-030-000	WASHER B; HANDLE HOLDER SETTING	2	2	
29	92000-06025	BOLT; HEX.; 6X25	2	2	
30	93500-05078-4J	SCREW; PAN; 5X28	2	2	
31	94001-06000	NUT; HEX.; 6MM	4	3	
32	94101-05000	WASHER; PLAIN; 5MM	2	2	
33	94101-06000	WASHER; PLAIN; 6MM	3	3	
34	94111-07000	WASHER; SPRING; 6MM	1		
35	98200-11500	FUSE A (15A)	1	1	