


# F - 20

## Pedal / Kick Starter Arm



Service item	F.R.T.	No.	Part Number	Description	QTY	Notes
1 PEDAL, GEAR CHANGE .....	0.2	1	24701-KGH-901	PEDAL, GEAR CHANGE	1	
8 JOINT, KICK STARTER ARM .....	0.2	2	24703-KGH-901	WASHER, CHANGE PEDAL	1	
10 ARM, KICK STARTER .....	0.1	3	24703-KW6-841	WASHER, NYLON, 7MM	2	
		4	24711-KWC-900	ARM COMP., GEAR CHANGE	1	
12 SWITCH, REAR STOP :PEDAL SIDE ....	0.5	5	24720-KGH-901	ROD, TIE	1	
14 PEDAL, REAR BRAKE .....	0.2	6	24721-KW6-961	COVER, CHANGE PEDAL	2	
		7	24781-449-001	RUBBER, GEAR CHANGE	1	
		8	28241-KET-901	JOINT, KICK ARM	1	
		9	28293-333-000	CLIP, KICK STARTER ARM	1	
		10	28300-KGH-600	ARM ASSY., KICK STARTER	1	
		11	28333-KAN-T41	SPRING, KICK STARTER STOPPER	1	
		12	35350-KGH-731	SWITCH ASSY., RR. STOP	1	
		13	35357-GBG-851	SPRING, STOP SWITCH	1	
		14	46500-KGH-901	PEDAL COMP., RR. BRAKE	1	
		15	46514-KAN-941	SPRING, BRAKE PEDAL	1	
		16	46515-KGH-901	PLATE, SPRING SETTING	1	
		17	90405-ZA8-800	WASHER, WAVE, 15MM	1	
		18	90505-116-671	WASHER, 13X20	1	
		19	94201-20150	PIN, SPLIT, 2.0X15	2	
		20	94510-15000	CIRCLIP, EXTERNAL, 15MM	1	

PC KWCA 03-08