


F-7 Front Wheel



F-7 Front Wheel



Ref. No.	Part No.	Description	Reqd. No. SL125	Remarks
1	44801-110-000	AXLE, front wheel	1	
2	44311-229-000	COLLAR, front wheel side	1	
3	44601-107-770	HUB, front wheel (Used in U.S.A.)	1	
4	44601-028-000	(Superseded by 44601-107-770)..... (Used in France)	1	
5	44620-030-000	COLLAR, front axle distance	1	
6	44701-331-671	RIM, front wheel (DAIDO) (Used in U.S.A.)	1	
7	44701-074-003	RIM, front wheel (DAIDO) (Used in France)	1	
8	44711-331-671	(Superseded by 44711-331-672) (Used in U.S.A.)		
	44711-331-672	TIRE, front wheel (2.75-21) (NITTO)	1	
		(Used in U.S.A.)		
9	44711-074-006	(Superseded by 44711-074-016) (Used in France)		
	44711-074-016	TIRE, front wheel (2.75-19) (NITTO)	1	
		(Used in France)		
10	44712-331-671	TUBE, wheel (2.75-21) (NITTO).....	1	
		(Used in U.S.A.)		
11	44712-074-006	TUBE, front wheel (2.75-19) (NITTO).....	1	
		(Used in France)		
12	44713-331-671	FLAP, tire (Used in U.S.A.).....	1	
13	44713-028-000	FLAP, tire (Used in France)	1	
14	44806-331-671	GEAR, speedometer (Used in U.S.A.)	1	
15	44806-110-000	GEAR, speedometer (Used in France)	1	
16	45010-331-671	PANEL, front brake (Used in U.S.A.)	1	
17	45010-110-000	PANEL, front brake (Used in France).....	1	
18	45120-001-010	SHOE COMP., brake	2	
19	45131-030-000	CAM, front brake	1	
20	45133-028-000	SPRING, brake shoe	2	
21	45410-028-000	ARM, front brake	1	
22	45437-001-000	SPRING, front brake arm	1	
23	45436-001-000	NUT, front brake arm setting	1	
24	45461-001-000	(Superseded by 95015-31000)		
	95015-31000	JOINT, front brake arm	1	
25	45462-028-000	(Superseded by 95015-41000)		
	95015-41000	NUT, front brake	1	