



Ref. No.	Part No.	Description	Reqd. No. SL125	Remarks
1	17247-240-000	GROMMET A, air cleaner case .....	1	
2	30250-107-000	CONDENSER ASSY. ....	1	
3	30400-107-007	COIL COMP., ignition (HONDA LOCK) ...	1	
4	30507-107-000	COLLAR, ignition coil setting .....	2	
5	30700-259-810	CAP ASSY., noise suppressor (Used in U.S.A.)	1	
6	30700-243-610	CAP ASSY., noise suppressor (Used in France)	1	
7	31468-107-000	COVER, battery terminal .....	1	
8	31500-110-671	BATTERY ASSY. (Used in U.S.A.) .....	1	
9	31500-107-681	(Superseded by 31500-107-682) (Used in France)	1	SL125S - ~1037302
	31500-107-682	(Superseded by 31500-324-601) (Used in France)	1	SL125S-1037303~
	31500-324-601	BATTERY ASSY. (Used in France) .....	1	
10	31503-044-670	RUBBER B, battery mount .....	1	
11	31511-107-300	CUSHION B, battery .....	1	
12	31701-107-003	(Superseded by 31701-107-701)		
	31701-107-701	RECTIFIER COMP., selenium .....	1	
13	31705-110-000	STAY, selenium rectifier .....	1	SL125S - ~1037302
	31707-110-000	STAY, selenium rectifier .....	1	SL125S-1037303~
14	32100-110-770	HARNESS, wire (Used in U.S.A.) .....	1	
15	32100-331-010	HARNESS, wire (Used in France) .....	1	
16	32111-240-000	CASE, fuse connector .....	1	
17	32113-107-000	HOLDER, fuse .....	1	
18	32161-001-000	BAND, wire harness .....	1	
19	35010-111-671	SWITCH-KIT, combination .....	1	
20	35100-111-671	SWITCH ASSY., combination .....	1	
21	38100-110-671	HORN ASSY. (Used in U.S.A.) .....	1	
22	38100-331-621	HORN ASSY. (Used in France) .....	1	
23	38300-107-004	RELAY ASSY., winker (Used in France) ...	1	
24	38306-292-000	SUSPENSION, winker relay (Used in France)	1	
25	50375-331-000	BRACKET, main switch .....	1	