

## CONTENTS

		Page
E - 1	CYLINDER • CYLINDER HEAD	3
E - 2	CAMSHAFT • VALVE	4
E - 3	RIGHT CRANKCASE COVER	5
E - 4	OIL PUMP	6
E - 5	CLUTCH	7
E - 6	LEFT CRANKCASE COVER • GENERATOR	8
E - 7	CRANKCASE	9
E - 8	CRANK SHAFT • PISTON	10
E - 9	TRANSMISSION	11
E - 10	KICK STARTER	12
E - 11	GEARSHIFT DRUM	13
E - 12	CARBURETOR	14
F - 1	HEADLIGHT	15
F - 2	HANDLE LEVER • DIMMER SWITCH	16
F - 3	SPEEDOMETER	17
F - 4	STEERING HANDLE • TOP BRIDGE	18
F - 5	FRONT FENDER • FRONT WHEEL • FRONT BRAKE PANEL	19
F - 6A	FRONT FORK NEW	20
F - 7	REAR BRAKE PANEL	21
F - 8	REAR WHEEL	22
F - 9	FUEL TANK • FUEL COCK	23
F - 10	DUAL SEAT	24
F - 11	SIDE COVER	25
F - 12	AIR CLEANER	26
F - 13	MAINSTAND • KICK STARTER ARM • STEP BAR	27
F - 14	EXHAUST MUFFLER	28
F - 15	REAR FORK • CHAIN CASE	29
F - 16	REAR CUSHION	30
F - 17	REAR FENDER	31
F - 18	TAIL LIGHT • WINKER ASSY	32
F - 19	WIRE HARNESS • IGNITION COIL	33
F - 20	FRAME BODY	34
	PART NO. INDEX	35