


F - 13

MAIN STAND • KICK STARTER ARM • STEP BAR



Service item	F.R.T.
PEDAL, GEAR CHANGE	0.1
•ARM ASSY., KICK STARTER	
•SPRING, STOP SWITCH	
•HOOK, MAIN STAND SPRING	
•SPRING A, SIDE STAND	
SWITCH ASSY., STOP	0.2
•STAND COMP., SIDE	
ROD, RR. BRAKE	0.4
•PEDAL COMP., BRAKE	
•BAR COMP., STEP	
STAND COMP., MAIN	0.5

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	REQ'D. NO. OLD	NEW
1	24701-397-000	PEDAL, GEAR CHANGE	21	95011-40000	RUBBER, CHANGE PEDAL	21	1	1
2	28300-KCS-650	ARM ASSY., KICK STARTER	22	95011-31000	STEP RUBBER A, PILLION	22	1	1
3	35350-KJ9-405	SWITCH ASSY., STOP	23	95014-71202	SPRING B, MAINSTAND	23	1	1
4	35357-107-010	SPRING, STOP SWITCH	24	95014-73100	SPRING A, BRAKE ROD	24	1	1
5	43451-088-950	ROD, RR. BRAKE	25	95015-31001	JOINT A, BRAKE ARM	25	1	1
6	46500-KB5-000	PEDAL COMP., BRAKE	26	95015-42000	NUT B, BRAKE ROD ADJUSTING	26	1	1
7	46514-107-010	SPRING, BRAKE PEDAL						
8	50500-108-762	STAND COMP., MAIN						
9	50523-383-660	HOOK, MAIN STAND SPRING						
10	50524-397-000	RUBBER, STAND STOPPER						
11	50526-383-670	SHAFT, MAIN STAND PIVOT						
12	50610-KB5-900ZA	BAR COMP., STEP						
13	50661-383-670	RUBBER, STEP						
14	90521-028-000	WASHER, 17X22						
15	92101-06020-0A	BOLT, HEX., 6X20						
16	92101-08040	BOLT, HEX., 8X40						
17	93482-08020-00	BOLT, WASHER, 8X20						
18	94101-05000	WASHER, PLAIN 5MM						
19	94201-16150	PIN, SPLIT, 1.6						
20	94201-30250	PIN, SPLIT, 3.0X25						