

# PART NAME INDEX

Part name	Address	Page	Ref.	Part name	Address	Page	Ref.	Part name	Address	Page	Ref.
CHAIN, DRIVE .....	G7	68	2	COVER SET, RR. CENTER .....	G1	62	3	FENDER, RR. ....	G9	70	2
CHAMBER SET, FLOAT .....	E5	44	5	COVER SET, R. MAIN PIPE SIDE ..	G16	77	3	FLANGE SUB ASSY., FINAL DRIVEN	F13	58	7
CIRCLIP .....	F4	49	16	COVER SUB ASSY., AIR CLEANER ..	G2	63	6	FLAP, TIRE .....	F10	55	2
CIRCLIP, 7MM .....	D6	29	16	COVER, BATTERY .....	G12	73	2	F13	F13	58	15
	D8	31	26	COVER, CENTER .....	G1	62	2	FLOAT SET .....	E5	44	3
CIRCLIP, EXTERNAL, 17MM .....	E1	40	23	COVER, HEAD PIPE .....	G16	77	4	FLYWHEEL COMP. ....	D12	35	1
CIRCLIP, INTERNAL, 45MM .....	D8	31	24	COVER, L. CRANKCASE .....	D11	34	1	FORK ASSY., L. FR. ....	F8	53	14
CLAMP .....	F2	47	3	COVER, L. CYLINDER HEAD SIDE ..	D1	24	6	FORK ASSY., R. FR. ....	F8	53	1
CLAMPER B, BRAKE HOSE .....	F4	49	3	COVER, L. DRAIN .....	F1	46	5	FORK, L. GEARSHIFT .....	E3	42	2
CLAMPER B, FR. BRAKE HOSE .....	F6	51	2	COVER, OIL FILTER .....	D7	30	1	FORK, R. GEARSHIFT .....	E3	42	1
CLAMPER, CORD .....	G13	74	4	COVER, R. DRAIN .....	F1	46	4	FUEL UNIT .....	F15	60	6
CLAMPER, FUEL TUBE .....	D1	24	14	COVER, SEAT LOCK .....	F16	61	5	FUSE, MINI .....	G13	74	21
CLAMP, OVER FLOW PIPE .....	D11	34	4	COVER, TAPPET ADJUSTING HOLE ..	D1	24	7				22
CLAMP, TUBE .....	G2	63	13	COWL SUB ASSY., FR. ....	F1	46	3	[ G ]			
CLIP, BATTERY COVER .....	G12	73	12	COWL, UNDER .....	G16	77	7	GASKET SET .....	E5	44	1
CLIP, HARNESS .....	G9	70	5	CRANKCASE COMP., L. ....	D15	38	3	GASKET SET B .....	E5	44	10
CLIP, HARNESS BAND .....	G13	74	16	CRANKCASE COMP., R. ....	D15	38	1	GASKET, CARBURETOR INSULATOR ..	D1	24	11
CLIP, PISTON PIN, 13MM .....	D16	39	5	CRANKSHAFT COMP. ....	D16	39	1	GASKET, CYLINDER .....	D5	28	2
CLIP, SWITCH COVER .....	G4	65	10	CUP, FUEL STRAINER .....	E5	44	20	GASKET, CYLINDER HEAD .....	D1	24	5
CLIP, TRIM .....	G12	73	13	CUSHION ASSY., RR. ....	G8	69	1	GASKET, CYLINDER HEAD .....	D1	24	5
CLIP, TUBE .....	D15	38	17	CUSHION, C.D.I. UNIT .....	G13	74	1	GASKET, EX. PIPE .....	G3	64	1
	E6	45	30		G14	75	2				
	F15	60	11	CYLINDER COMP. ....	D5	28	1				
	G2	63	14	CYLINDER SET, MASTER .....	F4	49	11	GASKET, FLOAT CHAMBER .....	E5	44	18
			15	CYLINDER SUB ASSY., FR. BRAKE				GASKET, L. CRANKCASE COVER .....	D11	34	3
CLIP, VALVE GUIDE .....	D1	24	2	MASTER	F4	49	5	GASKET, L. CYLINDER HEAD SIDE			
CLIP, WIRE HARNESS .....	G12	73	14	C.D.I. UNIT .....	G13	74	2	COVER	D1	24	8
CLUTCH ASSY., ONE WAY .....	D13	36	2	[ D ]				GASKET, OIL FILTER .....	D7	30	2
COIL ASSY., IGNITION .....	G13	74	3	DAMPER SET, WHEEL .....	F13	58	1	GASKET, R. CRANKCASE COVER .....	D6	29	3
COLLAR, 6.2X17 .....	G12	73	11	DIAPHRAGM .....	F4	49	9	GASKET, TENSIONER LIFTER .....	D4	27	6
COLLAR, 6.2X22.5 .....	G12	73	10	DISK, CLUTCH FRICTION .....	D9	32	5	GAUGE, OIL LEVEL .....	D6	29	4
COLLAR, 6.5X11X3 .....	G5	66	8	DISK, FR. BRAKE .....	F10	55	16	GEAR COMP., PRIMARY DRIVE .....	D7	30	14
COLLAR, CLUTCH OUTER .....	D9	32	3	DOWEL PIN, 10X12 .....	D5	28	3	GEAR COMP., STARTER DRIVEN .....	D13	36	1
COLLAR, FR. AXLE DISTANCE .....	F10	55	7	DOWEL PIN, 3X5 .....	D15	38	16	GEAR, COUNTERSHAFT FIRST .....	E1	40	4
COLLAR, FR. FENDER .....	F7	52	5	DOWEL PIN, 8X12 .....	D3	26	15	GEAR, COUNTERSHAFT FOURTH .....	E1	40	10
COLLAR, FR. WHEEL SIDE .....	F10	55	4		D6	29	17	GEAR, COUNTERSHAFT SECOND .....	E1	40	6
COLLAR, HORN SETTING .....	G13	74	11	DRIVER, SCREW .....	G15	76	2	GEAR, COUNTERSHAFT THIRD .....	E1	40	8
COLLAR, KICK RETAINER .....	E4	43	5	DRUM, GEARSHIFT .....	E3	42	4	GEAR, MAINSHAFT FOURTH .....	E1	40	9
COLLAR, KICK SPRING .....	E4	43	8	DUST SEAL .....	F8	53	8	GEAR, MAINSHAFT SECOND .....	E1	40	5
COLLAR, LOCK PLATE .....	E1	40	13	DUST SEAL, 21X37X7 .....	F10	55	19	GEAR, MAINSHAFT THIRD .....	E1	40	7
COLLAR, MAIN PIPE COVER .....	H1	78	15	DUST SEAL, 27X40X4.5 .....	F14	59	20	GEAR, OIL PUMP DRIVE .....	D16	39	6
COLLAR, MAIN STEP MOUNTING .....	G5	66	6	DUST SEAL, 40X50X5 .....	F11	56	20	GEAR, OIL PUMP DRIVEN .....	D10	33	2
COLLAR, MUFFLER MOUNTING .....	G5	66	2	DUST SEAL, BRAKE CAM .....	F12	57	9	GEAR, SPEEDOMETER .....	F10	55	14
COLLAR, RR. AXLE DISTANCE .....	F13	58	8	DUST SEAL, STEERING HEAD .....	F6	51	6	GEAR, STARTER REDUCTION .....	D13	36	3
COLLAR, RR. BRAKE PANEL SIDE ..	F12	57	3	[ E ]				GRIP .....	G15	76	3
COLLAR, RR. FENDER .....	H1	78	14	ELEMENT COMP., AIR CLEANER .....	G2	63	1	GRIP COMP., THROTTLE .....	F3	48	7
COLLAR, RR. WHEEL SIDE .....	F13	58	6	EMBLEM, PRODUCT .....	F5	50	13	GRIP, L. HANDLE .....	F3	48	8
COLLAR, RUBBER BUSH .....	G8	69	2	E-RING, 6MM .....	D10	33	8	GROMMET, AIR CLEANER CASE .....	G1	62	4
COLLAR, RUBBER BUSH .....	G8	69	2	[ F ]				GROMMET, WIRE .....	F7	52	2
COLLAR, SETTING .....	F2	47	12	FENDER COMP., FR. ....	F7	52	3	GUIDE COMP., CAM CHAIN .....	D4	27	7
COLLAR, SPRING .....	F8	53	3					GUIDE, CLUTCH OUTER .....	D9	32	2
COLLAR, STARTER REDUCTION .....	D13	36	5					GUIDE, VALVE .....	D1	24	4
COLLAR, TAILLIGHT MOUNTING .....	G11	72	6								
COLLAR, TOP BRIDGE .....	F5	50	11					[ H ]			
COTTER, VALVE .....	D3	26	12					HANDLE, EYE WRENCH .....	G15	76	8
COUNTERSHAFT .....	E1	40	2					HARNESS, WIRE .....	G13	74	7
COVER COMP., L. RR. ....	D11	34	2					HEADLIGHT UNIT .....	F1	46	1
COVER COMP., R. CRANKCASE .....	D6	29	1					HEAD COMP., CYLINDER .....	D1	24	1
COVER SET, L. MAIN PIPE SIDE ..	G16	77	10								
	H1	78	10								

