

PART NAME INDEX

J 4

Part name	Address	Page	Ref.	Part name	Address	Page	Ref.	Part name	Address	Page	Ref.
PLATE, BEARING	D15	38	6	RUBBER B, SEAT MOUNTING	F2	47	13	SEAT COMP., DOUBLE	F16	61	2
PLATE, BEARING HOLDER	E1	40	18	RUBBER C, SEAT SETTING	F16	61	4	SEAT, VALVE SPRING	D3	26	11
PLATE, CLUTCH	D9	32	6	RUBBER, CHANGE PEDAL	G4	65	14	SEAT, VALVE SPRING OUTER	D3	26	10
PLATE, CLUTCH LIFTER	D9	32	8	RUBBER, CLUTCH DAMPER	D7	30	13	SET RING, 20MM	E2	41	24
PLATE, CLUTCH PRESSURE	D9	32	7	RUBBER, KICK STARTER	G4	65	3		E4	43	11
PLATE, CLUTCH SIDE	D7	30	10	RUBBER, LUGGAGE BOX BOTTOM	G12	73	5	SET RING, 25MM	D8	31	25
PLATE, DIAPHRAGM	F4	49	10	RUBBER, LUGGAGE BOX MOUNTING ..	G12	73	6	SHAFT, EX. ROCKER ARM	D3	26	5
PLATE, DRUM LOCK	E1	40	15					SHAFT, GEARSHIFT FORK	E3	42	3
PLATE, FIXING	E1	40	12	RUBBER, L. SILENCER	G16	77	9	SHAFT, IN. ROCKER ARM	D3	26	4
PLATE, PILLION STEP LOWER	G5	66	9	RUBBER, MAIN STEP	G5	66	12	SHAFT, REDUCTION GEAR	D13	36	4
PLATE, PILLION STEP SIDE	G5	66	13	RUBBER, MAIN STEP MOUNTING	G5	66	7	SHAFT, RR. BRAKE PIVOT	G6	67	2
PLATE, STOPPER	D1	24	3	RUBBER, MUFFLER MOUNTING	G5	66	1	SHOE SET, BRAKE	F12	57	1
PLATE, TENSIONER SETTING	D4	27	4	RUBBER, R. SILENCER	G16	77	8	SLEEVE, RR. WHEEL	F13	58	5
PLIERS, 135	G15	76	6	RUBBER, SEAL	F16	61	1	SLIDER, CHAIN	G7	68	7
PLUG, BEARING PUSH	D15	38	4	RUBBER, SEAT LOCK	H1	78	11	SOCKET COMP.	F2	47	8
PLUG, SPARK	D1	24	16	RUBBER, STAND STOPPER	G6	67	4	SOCKET COMP., HEADLIGHT	F1	46	2
PLUNGER, CAM SETTING	D1	24	9	RUBBER, STEP	G5	66	11	SOCKET COMP., L. WINKER	G10	71	7
PROTECTOR	F4	49	6	RUBBER, STOPPER ARM	F12	57	7	SOCKET COMP., R. WINKER	G10	71	4
PROTECTOR COMP., R. COVER	D6	29	2	RUBBER, TAILLIGHT BRACKET	G13	74	9	SPANNER, 10X12	G15	76	4
PUMP ASSY., OIL	D10	33	1	RUBBER, TAILLIGHT MOUNTING	G11	72	5	SPANNER, 14X17	G15	76	5
							8	SPEEDOMETER COMP.	F2	47	4
[R]				[S]				SPINDLE COMP., GEARSHIFT	E3	42	9
RACE, STEERING BOTTOM CONE	F6	51	5	SCREEN, FUEL STRAINER	E5	44	21	SPINDLE, KICK STARTER	E4	43	3
RACE, STEERING TOP BALL	F6	51	3	SCREEN, OIL FILTER	D10	33	5	SPOKE SET	F10	55	5
RACE, STEERING TOP CONE	F6	51	4	SCREW-WASHER, 3X12	E6	45	26	SPOKE SET A, 10X158.5	F13	58	3
RAIL, RR. GRAB	F16	61	7	SCREW-WASHER, 3X22	F2	47	9	SPOKE SET A, 10X159.0	F13	58	2
RATCHET, STARTER DRIVE	E4	43	2	SCREW-WASHER, 4X10	E6	45	27	SPRING ASSY., RR. BRAKE RETURN	G4	65	9
RECTIFIER COMP., REGULATE	G13	74	6	SCREW-WASHER, 4X12	F4	49	18	SPRING A, BRAKE ROD	G4	65	15
REFLECTOR, L.	G10	71	6	SCREW-WASHER, 4X14	E6	45	28	SPRING A, MAIN STAND	G6	67	9
REFLECTOR, RR. REFLEX	G9	70	1	SCREW-WASHER, 5X10	E6	45	29	SPRING A, SIDE STAND	G6	67	10
REFLECTOR, R.	G10	71	3	SCREW-WASHER, SPECIAL, 4X10	F2	47	15	SPRING, BEARING PUSH	D15	38	5
RELAY COMP., STARTER	G13	74	14	SCREW SET	E5	44	6	SPRING, BRAKE	D6	29	11
RELAY COMP., WINKER	G13	74	12	SCREW, BLEEDER	F9	54	3	SPRING, BRAKE SHOE	F12	57	8
RETAINER COMP., BALL	D6	29	12	SCREW, FLAT, 4X12	F4	49	17	SPRING, CAM PLATE SIDE	D6	29	7
RETAINER, FUEL UNIT	F15	60	8	SCREW, OVAL, 6X70	F5	50	15	SPRING, CARBON BRUSH	D14	37	3
RETAINER, GEAR BOX	F10	55	10	SCREW, PAN, 5X10	F3	48	15	SPRING, CHANGE FRICTION	E1	40	14
RETAINER, KICK SPRING	E4	43	4	SCREW, PAN, 5X11.5	G1	62	7	SPRING, CHANGE SWITCH CONTACT	E3	42	15
RETAINER, SPRING	D7	30	16	SCREW, PAN, 5X20	F3	48	16	SPRING, CLUTCH	D9	32	9
	D8	31	16	SCREW, PAN, 5X25	F3	48	17	SPRING, FR. FORK	F8	53	2
RETAINER, VALVE SPRING	D3	26	9	SCREW, PAN, 6X6	D4	27	8	SPRING, FR. FORK	F8	53	2
RIM, FR. WHEEL	F10	55	11	SCREW, SIDE STAND PIVOT	G6	67	6	SPRING, GEARSHIFT ARM	E3	42	11
RIM, RR. WHEEL	F13	58	12	SCREW, TAPPET ADJUSTING	D3	26	13	SPRING, GEARSHIFT RETURN	E3	42	12
RING	D14	37	6	SCREW, TAPPING, 4X12	F1	46	13	SPRING, KICK RETURN	E4	43	7
RING SET, PISTON	D16	39	2	SCREW, TAPPING, 4X14	F2	47	16	SPRING, ONE WAY RETAINER	D7	30	4
RING, HANDLE WEIGHT SNAP	F5	50	9	SCREW, TAPPING, 4X16	G11	72	12	SPRING, PAD	F9	54	6
RING, OIL SEAL STOPPER	F8	53	11	SCREW, TAPPING, 4X20	G10	71	9	SPRING, PLUNGER	D1	24	10
RING, PISTON	F8	53	10	SCREW, TAPPING, 5X16	F1	46	14	SPRING, PRIMARY CLUTCH	D7	30	7
RING, SNAP	F8	53	19	SCREW, TAPPING, 5X25	G2	63	12	SPRING, REBOUND	F8	53	6
RING, STOPPER	F9	54	7	SCREW, U-LOCK FLAT, 6X12	F5	50	14	SPRING, SHIFT DRUM STOPPER	E3	42	8
ROD COMP., RR. BRAKE	G4	65	6	SEAL SET, FR. FORK	F8	53	13	SPRING, SIDE FRICTION	D7	30	9
ROLLER, 3X8.5	E3	42	19	SEAL SET, PISTON	F9	54	1	SPRING, STARTER PINION			
ROLLER, 4X10.8	E3	42	18	SEAL, AIR CLEANER COVER	G2	63	2	FRICTION	E4	43	6
ROLLER, 4X23.8	D10	33	10	SEAL, VALVE STEM	D3	26	1	SPRING, STOP SWITCH	G4	65	5
ROLLER, 5X8	D8	31	27					SPRING, SUB GEAR	D8	31	17
ROTOR, OIL PUMP INNER	D10	33	3					SPRING, VALVE	D3	26	8
ROTOR, OIL PUMP OUTER	D10	33	4					SPROCKET, CAM	D4	27	1
RUBBER A, HANDLE WEIGHT	F5	50	8					SPROCKET, DRIVE	E1	40	11
RUBBER A, STAND STOPPER	F16	61	11					SPROCKET, FINAL DRIVEN	F13	58	4
								STAND COMP., MAIN	G6	67	1

