


F-29

PEDAL

Ref. No.	L.O.N.	(Relative ref. Number)	Description	F.R.T.
2	4101A1		PEDAL, GEAR CHANGE	0.1
5	112107		ARM, KICK STARTER	0.1
8	6151B5		SWITCH, REAR STOP	0.4
10	810160		PEDAL, REAR BRAKE	0.2



Ref. No.	Part No.	Description	Reqd. QTY			Serial No.	Parts catalogue code
			CB	150R	H		
1	16502-880-000	WASHER, SWITCH BOSS	1				
2	24701-K15-920	PEDAL, GEAR CHANGE	1				
3	24781-KR3-770	RUBBER, GEAR CHANGE PEDAL	1				
4	28293-333-000	CLIP, KICK STARTER ARM	1				
5	28300-K15-920	ARM ASSY., KICK STARTER	1				
6	28311-K15-900	RUBBER, KICK STARTER	1				
7	28333-KK0-000	SPRING, KICK STARTER	1				
8	33350-K15-921	SWITCH ASSY., RR. STOP	1				
9	33357-HP0-A00	SPRING, STOP SWITCH	1				
10	46500-K15-920	PEDAL COMP., BRAKE	1				
11	46514-KZ4-J00	SPRING, BRAKE PEDAL	1				
12	90102-MN1-670	BOLT, FLANGE, 6X20	1				
13	90505-KRM-860	WASHER, 15.5X22	1				
14	90601-KAF-003	CLIP, SWITCH COVER	1				
15	94201-25220	PIN, SPLIT, 2.5X22	1				
16	95701-08035-07	BOLT, FLANGE, 8X35	1				
17	96211-08000	BALL, STEEL, #8(1/4)	1				