


F-37

BATTERY

Ref. No. L.O.N. (Relative ref. Number) Description F.R.T.

1 610100 BATTERY 0.2
 2 610110 CABLE, NEGATIVE BATTERY 0.3
 3 615113 SWITCH, STARTER MAGNETIC 0.2



Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			CB 150R H		
1	31500-KZR-602	BATTERY(GTZ6V)(GS YUASA)	1		
2	32412-K15-920	CABLE, EARTH	1		
3	35850-K18-901	SWITCH ASSY., STARTER MAGNETIC	1		
4	35856-K15-901	RUBBER, SHOCK (MAGNETIC)	1		
5	80102-K45-N00	BAND COMP., BATTERY	1		
6	94050-06000	NUT, FLANGE, 6MM	2		
7	95701-06012-08	BOLT, FLANGE, 6X12	1		
8	95701-06014-00	BOLT, FLANGE, 6X14	1		