



When the parts were revised



Be sure to check the serial number!!



Abbreviations used in the parts catalogue



RIGHT is abbreviated as "R."

"L." stands for LEFT

Ref. No.	Part No.	Description	Reqd. QTY		Serial No.
			CB400	SFX SFY	
1	45156-MCE-000	CLAMPER, R. FR. BRAKE HOSE	1	1	
2	45157-MCE-000	CLAMPER, L. FR. BRAKE HOSE	1	1	
3	61100-MCE-000ZA	FENDER COMP., FR. *NH411M*FORCE SILVER METALLIC	1	1	-----3J,4J
4	61100-MCE-000ZB	*PB284C*...CANDY PHOENIX BLUE	1	1	-----J,2J
6	61101-MCE-000	PLATE, FR. FENDER (###)	2	2	1008000
6	61101-MCE-010	2	2	1008001
5	61102-MCE-300	CUSHION, FR. FENDER (BLACK)	2	2	1008000
6	61105-MCE-000	STAY, FR. FENDER MOUNTING	2	2	
7	61107-M67-000	COLLAR (6.5)	4	4	
8	96001-06020-00	BOLT, FLANGE, 6X20	4	4	

The number has been When shown at the left side, When shown at the right side, used from the initial model it is applicable to the models it is applicable to the models of No.1008001 and the up to No.1008000. without revision. subsequent numbers.

The parts listed with "###" at the end of the parts name have limited supply period (parts not for sale).

* "L." or "R." in the description of a part stands for the LEFT hand side or the RIGHT hand side. Determine the left or right as if you were in the motorcycle seat.

The following abbreviations are used in this parts catalogue.

- AAmpere
- ABSAnti-lock brake system
- A.C.Alternating current
- A.M.Attaching mark
- ASSY.Assembly
- C.D.I.Capacitive discharge ignition
- COMP.Complete
- CP.Candle power
- D.C.Direct current
- EX.Exhaust
- FR.Front
- GGram
- HEX.Hexagonal
- IN.Inlet
- KPHKilometers per hour
- L.Left
- L (100L) ...Link (100 Links)
- L.E.D.Light emitted diode
- MMMillimeter
- MPHMiles per hour
- R.Right
- RR.Rear
- STD.Standard
- T (22T)Tooth (22 Teeth)
- TCSTraction control system
- T.M.Transcript mark
- VVolt
- WWatt
- WLWith labelling
- WOLWithout labelling