


Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
+38			
2101C9		.INCLUDES: Engine removal and installation BEARING, COUNTERSHAFT :BOTH ..	5.5
2101D4		.INCLUDES: Engine removal and installation BEARING, MAINSHAFT AND COUNTERSHAFT :ALL ..	5.7
39 2101G7		.INCLUDES: Engine removal and installation OIL SEAL, COUNTERSHAFT :LEFT ..	5.1



Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
25	90402-KVK-900	WASHER, THRUST, 20X19X1.0	1		
26	90412-187-000	WASHER, THRUST, 15MM	1		
27	90412-K56-N00	WASHER, SPECIAL, 15MM	1		
28	90441-KW7-930	PLATE, BEARING HOLDER	1		
29	90451-K56-N00	WASHER, SPLINE, 20MM	1		
30	90452-KGH-900	WASHER, SPECIAL, 12MM	1		
31	90452-KRM-840	WASHER, SPLINE, 17X23X1.6	2		
32	90454-KPH-900	WASHER, 25X20.2X1	3		
33	90601-KRM-840	CIRCLIP, 17MM	2		
34	90605-KVS-900	SET RING, 20MM	1		
35	91004-K56-N01	BEARING, RADIAL BALL, 6202U (SKF)	1		
36	91005-K56-N01	BEARING, RADIAL BALL, 6201U (SKF)	1		
37	91006-K56-N01	BEARING, RADIAL BALL, 6203 (SKF)	1		
	91006-K56-N02	BEARING, RADIAL BALL, 6203 (FUJIKOSHI)	1		
38	91010-K56-N01	BEARING, RADIAL BALL, 6204 (SKF)	1		
39	91216-KGH-901	OIL SEAL, 20X34X7	1		
40	95701-06014-00	BOLT, FLANGE, 6X14	2		

