

PART NAME INDEX

Part name	Page	Ref.	Part name	Page	Ref.	Part name	Page	Ref.
[A]								
ADJUSTER COMP., CHAIN	83	4	BOLT, CLUTCH WIRE ADJUSTING	57	15	BOLT, FLANGE, 6X25	54	8
ARM COMP., EX. VALVE ROCKER	34	5	BOLT, CYLINDER STUD	47	8	BOLT, FLANGE, 6X28	93	36
ARM COMP., GEAR CHANGE	79	1	BOLT, DRAIN PLUG, 12MM	47	13	BOLT, FLANGE, 6X30	45	12
ARM COMP., IN. VALVE ROCKER	34	4	BOLT, DRIVE SPROCKET FIXING	50	20	BOLT, FLANGE, 6X30	39	18
ARM SUB ASSY., CUSHION	84	5	BOLT, FLANGE, 10X106	84	8	BOLT, FLANGE, 6X32	42	10
ARM, L. MAIN STEP	80	10	BOLT, FLANGE, 10X120	91	16	BOLT, FLANGE, 6X32	32	10
ARM, R. MAIN STEP	80	6	BOLT, FLANGE, 10X130	84	9	BOLT, FLANGE, 6X35	61	9
AXLE, FR. WHEEL	64	3	BOLT, FLANGE, 10X239	91	17	BOLT, FLANGE, 6X40	42	11
AXLE, RR. WHEEL	69	3	BOLT, FLANGE, 10X53	91	12	BOLT, FLANGE, 6X40	46	15
			BOLT, FLANGE, 10X55	84	11		47	7
			BOLT, FLANGE, 6MM	84	10		32	11
				83	10		39	19
[B]				85	13		42	12
BAG, OWNERS MANUAL	98	2	BOLT, FLANGE, 6X10	92	24	BOLT, FLANGE, 6X6	47	19
BAG, TOOL, 160MM	98	6		67	24	BOLT, FLANGE, 6X65	37	8
BALL ASSY., STEEL, #8X18	60	1		74	16	BOLT, FLANGE, 6X65	44	12
BALL, STEEL, #8	81	29		78	21		47	16
BAND, COMP., BATTERY	88	5	BOLT, FLANGE, 6X15	91	14	BOLT, FLANGE, 8X28	59	20
BAND, AIR CLEANER CONNECTING TUBE	77	14	BOLT, FLANGE, 6X12	33	22	BOLT, FLANGE, 8X30	73	26
BAND, HARNESS	47	11		58	22	BOLT, FLANGE, 8X32	95	33
BAND, NYLON	85	11		60	11	BOLT, FLANGE, 8X35	60	10
BAND, R. EX. PIPE	78	8		73	27	BOLT, FLANGE, 8X40	59	21
BAND, TOOL	85	12		85	22	BOLT, FLANGE, 8X45	78	22
BAND, WIRE	57	19	BOLT, FLANGE, 6X14	91	15	BOLT, FLANGE, 8X50	58	15
BAND, WIRE, 165MM	82	1		37	10	BOLT, HANDLE LEVER PIVOT	31	3
BAR COMP., SIDE STAND	80	17		39	11	BOLT, HEAD COVER	46	5
BAR, L. PILLION STEP	80	15		67	11	BOLT, HEX., 5X12	46	5
BAR, R. PILLION STEP	80	15		81	28	BOLT, HEX., 6X20	89	17
BATTERY	88	1		88	8	BOLT, L. STEERING HANDLE LEVER PIVOT	57	16
BEARING, NEEDLE, 17X24X17	84	14	BOLT, FLANGE, 6X16	43	5		58	16
BEARING, NEEDLE, 20X26X20	83	14		52	20		66	17
BEARING, RADIAL BALL	64	11		88	9		63	8
BEARING, RADIAL BALL SPECIAL, 6201	65	11		97	27		32	3
BEARING, RADIAL BALL, 12X32X10	49	16		97	27		45	4
BEARING, RADIAL BALL, 6004U0	49	16		43	5		73	22
BEARING, RADIAL BALL, 6201U	70	20		47	17		56	3
BEARING, RADIAL BALL, 6201U	51	36		52	20		67	26
BEARING, RADIAL BALL, 6202U	51	35		88	9		74	17
BEARING, RADIAL BALL, 6203	51	37		93	34		62	18
BEARING, RADIAL BALL, 6204	51	38		47	18		41	6
BEARING, RADIAL BALL, 6301	49	17		76	18		80	18
BEARING, RADIAL BALL, 6302U	70	19		89	20		91	11
BEARING, RADIAL BALL, 6903	40	16		53	13		78	16
BEARING, RADIAL BALL, 6905	52	18		77	24		80	19
BEARING, R. RADIAL BALL SPECIAL, 6207	49	15		79	17		94	23
BEARING, R. RADIAL BALL, 35X72X15	48	15		85	23		97	17
BODY COMP., FRAME	91	2		32	9		61	7
BODY SET	53	8		33	21		91	10
BOLT-WASHER, 5X25	86	8		37	12		70	15
BOLT-WASHER, 6X12	93	25		44	11		32	19
BOLT, BRAKE DISK, 8X24	64	9		53	17		83	11
	70	14		57	24		79	10
	59	16		58	23		59	15
	80	21		93	35		63	15
				40	11		63	10
				43	6		68	13

