

PART NAME INDEX

| Part name | Page | Ref. | Part name | Page | Ref. | Part name | Page | Ref. |
|-----------------------------------|------|------|---------------------------------------|------|------|--------------------------------------|------|------|
| BOOT COMP. | 58 | 5 | CIRCLIP | 58 | 18 | COLLAR, SPLINE, 17X20X11 | 50 | 13 |
| BOOT, HANDLE LEVER | 66 | 4 | CIRCLIP, 17MM | 66 | 14 | COLLAR, SPRING | 62 | 3 |
| BOOT, PIN BUSH | 57 | 14 | CIRCLIP, EXTERNAL, 15MM | 51 | 33 | COLLAR, STARTER REDUCTION | 41 | 5 |
| | 63 | 9 | CIRCLIP, EXTERNAL, 28MM | 79 | 16 | COLLAR, WATER PASS, 13X8 | 39 | 1 |
| | 68 | 12 | CIRCLIP, INTERNAL, 12MM | 49 | 18 | COLLAR, WINKER | 86 | 2 |
| BRACKET SUB ASSY., RR. | 68 | 7 | CIRCLIP, INTERNAL, 22MM | 39 | 14 | CONNECTOR | 66 | 3 |
| BRACKET SUB ASSY., R. FR. | 63 | 14 | CLAMPER A, FR. BRAKE HOSE | 58 | 17 | CONTACT ASSY., CHANGE SWITCH | 47 | 6 |
| BRACKET, HANDLE LEVER | 57 | 11 | CLAMPER B, FR. BRAKE HOSE | 58 | 3 | COTTER, VALVE | 34 | 13 |
| BRACKET, L. ENGINE HANGER | 91 | 8 | CLAMP, MASTER CYLINDER OIL HOSE | 66 | 4 | COUNTERSHAFT | 50 | 2 |
| BRACKET, L. UNDER COWL | 96 | 3 | CLAMP, TUBE | 77 | 1 | COVER COMP., L. RR. | 42 | 2 |
| BRACKET, RR. FENDER | 85 | 4 | | | 9 | COVER COMP., R. CRANKCASE | 39 | 2 |
| BRACKET, R. ENGINE HANGER | 91 | 7 | | | 18 | COVER COMP., WATER PUMP | 44 | 3 |
| BRACKET, R. UNDER COWL | 96 | 2 | | | 21 | COVER SET, FUEL TANK | 72 | 19 |
| BRIDGE, FORK TOP | 59 | 13 | | | 30 | COVER SUB ASSY., AIR CLEANER | 77 | 10 |
| BUSH, 15MM | 50 | 3 | | | 20 | COVER, CLUTCH SWITCH | 57 | 5 |
| BUSH, 20MM | 50 | 7 | | | 24 | COVER, CYLINDER HEAD | 31 | 1 |
| | | 15 | | | 24 | COVER, DUST | 79 | 3 |
| BUSH, 20MM | 50 | 10 | | | 1 | COVER, FUEL TANK | 72 | 20 |
| | | | | | 12 | COVER, L. CRANKCASE | 42 | 1 |
| | | | | | 75 | COVER, L. SIDE | 75 | 9 |
| | | | | | 85 | COVER, MUFFLER | 78 | 7 |
| | | | | | 54 | COVER, RELAY | 91 | 1 |
| CABLE COMP. A, THROTTLE | 57 | 1 | | | 6 | COVER, R. SIDE | 75 | 8 |
| CABLE COMP. B, THROTTLE | 57 | 2 | | | 18 | COVER, R. SIDE | 75 | 8 |
| CABLE COMP., CLUTCH | 57 | 3 | | | 30 | COVER, SEAT LOCK | 75 | 7 |
| CABLE, EARTH | 88 | 2 | | | 5 | COVER, SEAT LOCK | 45 | 8 |
| CABLE, STARTER MOTOR | 45 | 7 | | | 23 | COVER, STARTER MOTOR TERMINAL | 92 | 18 |
| CALIPER SUB ASSY., RR. | 68 | 6 | | | 13 | COVER, THERMOSTAT | 96 | 8 |
| CALIPER SUB ASSY., R. FR. | 63 | 13 | | | 25 | COWL ASSY., R. UNDER | 96 | 11 |
| CAWSHAFT COMP., EX. | 34 | 3 | | | 22 | COWL B, L. MIDDLE | 97 | 11 |
| CAWSHAFT COMP., IN. | 34 | 2 | | | 29 | COWL B, R. MIDDLE | 96 | 5 |
| CAP ASSY., NOISE SUPPRESSOR | 89 | 3 | | | 31 | COWL SET, FR. UPPER | 94 | 7 |
| CAP ASSY., RESERVE TANK | 92 | 11 | | | 1 | COWL SET, L. INNER MIDDLE | 97 | 12 |
| CAP COMP., FUEL FILLER | 72 | 15 | | | 3 | COWL SET, L. MIDDLE A | 96 | 10 |
| CAP COMP., RADIATOR | 92 | 6 | | | 4 | COWL SET, L. RR. | 75 | 5 |
| CAP, 14MM | 42 | 5 | | | 3 | COWL SET, L. UNDER | 97 | 14 |
| CAP, 30MM | 42 | 6 | | | 4 | COWL SET, R. CENTER | 75 | 6 |
| CAP, BLEEDER | 63 | 4 | | | 20 | COWL SET, R. INNER MIDDLE | 96 | 6 |
| | 68 | 10 | | | 1 | COWL SET, R. MIDDLE A | 96 | 4 |
| CAP, CHANGE SWITCH CONTACT | 52 | 13 | | | 8 | COWL SET, R. RR. | 75 | 4 |
| CAP, DUMMY | 89 | 7 | | | 1 | COWL, CENTER INNER LOWER | 96 | 7 |
| CAP, FORK PIPE | 62 | 12 | | | 6 | COWL, FR. LOWER | 94 | 12 |
| CAP, MASTER CYLINDER | 58 | 8 | | | 6 | COWL, FR. UPPER | 94 | 8 |
| | 66 | 8 | | | 5 | COWL, L. FR. INNER | 94 | 14 |
| | 91 | 9 | | | 2 | COWL, L. FR. SIDE | 94 | 11 |
| CAP, RR. FORK PIVOT | 56 | 4 | | | 5 | COWL, R. FR. INNER | 94 | 13 |
| CAP, SOCKET BOLT, 8MM | 59 | 4 | | | 4 | COWL, R. FR. SIDE | 94 | 10 |
| CAP, STEERING NUT | 83 | 5 | | | 11 | CRANKCASE COMP., R. | 47 | 1 |
| CAP, SWINGARM END | 78 | 3 | | | 4 | CRANKCASE SET, L. | 47 | 2 |
| CAP, TAIL | 55 | 5 | | | 5 | CRANKSHAFT COMP. | 48 | 1 |
| CASE ASSY., UNDER | 62 | 17 | | | 5 | CUP COMP., OIL | 66 | 6 |
| CASE ASSY., UPPER | 62 | 4 | | | 10 | CUSHION ASSY., RR. | 84 | 2 |
| CASE COMP., L. BOTTOM | 62 | 8 | | | 13 | CUSHION, FUEL TANK | 72 | 12 |
| CASE COMP., R. BOTTOM | 92 | 17 | | | 21 | | | 14 |
| CASE COMP., THERMOSTAT | 77 | 7 | | | 8 | CYLINDER COMP. | 38 | 1 |
| CASE SUB ASSY., AIR CLEANER | 83 | 1 | | | 5 | CYLINDER SET, MASTER | 58 | 12 |
| CASE, DRIVE CHAIN | 40 | 3 | | | 21 | CYLINDER SUB ASSY., FR. BRAKE | 58 | 6 |
| CENTER, CLUTCH | 37 | 1 | | | 3 | CYLINDER SUB ASSY., RR. MASTER | 66 | 5 |
| CHAIN, CAM | 83 | 2 | | | 69 | | | |
| CHAIN, DRIVE | | | | | | | | |

[C]