

| Ref. No. | L.O.N. | (Relative ref. Number)        | Description | F.R.T. |
|----------|--------|-------------------------------|-------------|--------|
| 1        | 4101A1 | PEDAL, GEAR CHANGE            | 0.2         |        |
| 3        | 4101A2 | ARM, GEAR CHANGE              | 0.2         |        |
| 4        | 5101B5 | ROD, CHANGE                   | 0.2         |        |
| 9        | 112107 | ARM, KICK STARTER             | 0.1         |        |
| 11       | 6151B5 | SWITCH, REAR STOP :PEDAL SIDE | 0.7         |        |
| 13       | 810160 | PEDAL, REAR BRAKE             | 0.2         |        |

| Ref. No. | Part No.       | Description               | Reqd. QTY |   | Serial No. | Parts catalogue code |
|----------|----------------|---------------------------|-----------|---|------------|----------------------|
|          |                |                           | FS        | G |            |                      |
| 1        | 24701-K56-N00  | PEDAL, GEAR CHANGE        | 1         |   |            |                      |
| 2        | 24703-KW6-840  | WASHER, NYLON, 7MM        | 2         |   |            |                      |
| 3        | 24711-K56-N00  | ARM COMP., GEAR CHANGE    | 1         |   |            |                      |
| 4        | 24720-K56-N00  | ROD, TIE                  | 1         |   |            |                      |
| 5        | 24721-K56-N00  | COVER, CHANGE PEDAL       | 1         |   |            |                      |
| 6        | 24722-K56-N00  | COVER B, CHANGE PEDAL     | 1         |   |            |                      |
| 7        | 24781-KRM-860  | RUBBER, GEAR CHANGE PEDAL | 1         |   |            |                      |
| 8        | 28293-333-000  | CLIP, KICK STARTER ARM    | 1         |   |            |                      |
| 9        | 28300-K56-N00  | ARM ASSY., KICK STARTER   | 1         |   |            |                      |
| 10       | 28333-KK0-000  | SPRING, KICK STARTER      | 1         |   |            |                      |
| 11       | 33350-K56-N01  | SWITCH ASSY., RR. STOP    | 1         |   |            |                      |
| 12       | 33357-KY1-000  | SPRING, STOP SWITCH       | 1         |   |            |                      |
| 13       | 46500-K56-N00  | PEDAL COMP., RR. BRAKE    | 1         |   |            |                      |
| 14       | 46514-K56-N00  | SPRING, BRAKE PEDAL       | 1         |   |            |                      |
| 15       | 90102-WN1-670  | BOLT, FLANGE, 6X20        | 1         |   |            |                      |
| 16       | 90505-KRM-860  | WASHER, 15.5X22           | 1         |   |            |                      |
| 17       | 90601-KAF-003  | CLIP, SWITCH COVER        | 1         |   |            |                      |
| 18       | 94201-20120    | PIN, SPLIT, 2.0X12        | 2         |   |            |                      |
| 19       | 95701-08035-07 | BOLT, FLANGE, 8X35        | 1         |   |            |                      |
| 20       | 96211-08000    | BALL, STEEL, #8(1/4)      | 1         |   |            |                      |