

PART NAME INDEX

Part name	Address	Page Ref.	Part name	Address	Page Ref.	Part name	Address	Page Ref.
[A]								
ADJUSTER COMP., CHAIN	G11	70	BOLT, FLANGE, 10X70	H2	77	BOLT, SOCKET, 6X22	D10	33
ARM ASSY., KICK STARTER	G8	67	BOLT, FLANGE, 5X14	D2	25	BOLT, SOCKET, 8MM	F7	50
ARM COMP., VALVE ROCKER	D3	26	BOLT, FLANGE, 6MM	G5	64	BOLT, STUD, 10X25	F11	54
ARM, FR. BRAKE	F12	55		G11	70	BOLT, STUD, 8X22	F15	58
ARM, RR. BRAKE	F14	57	BOLT, FLANGE, 6X10	H1	72	BOLT, SWINGARM PIVOT	D2	25
ARM, RR. BRAKE STOPPER	G11	70	BOLT, FLANGE, 6X10S	D2	25	BOLT, WIRE ADJUSTING	G11	70
AXLE, FR. WHEEL	F13	56	BOLT, FLANGE, 6X12	D1	24	BOOT, HEADLIGHT STAY LOWER	F1	44
AXLE, RR. WHEEL	F15	58		F7	50	BOOT, HEADLIGHT STAY UPPER	F1	44
			BOLT, FLANGE, 6X14	F8	51	BRACKET, AIR SUCTION VALVE	G6	65
				G6	65	BRACKET, L. HANDLE LEVER	F5	48
			BOLT, FLANGE, 6X16	D2	25	BRACKET, R. HANDLE LEVER	F5	48
				D2	25	BRIDGE, FORK TOP	F7	50
BAG, SERVICE BOOK	H3	78	BOLT, FLANGE, 6X18	G16	75	BRUSH SET, TERMINAL	D11	34
BAG, TOOL, 160MM	H3	78		D4	27	BULB, HEADLIGHT	F1	44
BALL ASSY., STEERING STEEL	F8	51	BOLT, FLANGE, 6X20	D13	36	BULB, POSITION LIGHT	F1	44
BALL, STEEL, #8	G8	67		E2	41	BULB, TAIL & STOP LIGHT	G15	74
BAND B1, WIRE	F5	48	BOLT, FLANGE, 6X22	G5	64	BULB, WEDGE BASE	F2	45
BAND, AIR CLEANER CONNECTING TUBE				G6	65			
			BOLT, FLANGE, 6X25	G13	72			
BAND, BATTERY	G5	64		D13	36			
BAND, INSULATOR	G16	75	BOLT, FLANGE, 6X28	D13	36	BULB, WINKER	G14	73
BAND, SELF LOCK	D2	25	BOLT, FLANGE, 6X30	F9	52	BUSH, 17X20.5X8.0	D15	38
BAND, SUCTION HOSE	F7	50		G8	67	BUSH, 20MM	E2	41
BAND, TOOL	H1	76	BOLT, FLANGE, 6X32	H1	76		D15	38
BAND, WIRE	G5	64		D4	27			
BAR, L. MAIN STEP	H1	76	BOLT, FLANGE, 6X35	D11	34	BUSH, SWINGARM PIVOT RUBBER	G11	70
BAR, L. PILLION STEP	G9	68		F6	49	BUSH, UPPER RUBBER	G12	71
BAR, R. MAIN STEP	G9	68	BOLT, FLANGE, 6X40	D7	30			
BAR, R. PILLION STEP	G9	68		D13	36			
BASE COMP., CONTACT	F7	50	BOLT, FLANGE, 6X45	G6	65			
BATTERY ASSY.	G16	75		D6	29			
BEARING, NEEDLE, 22X29X16.8	D8	31	BOLT, FLANGE, 6X70	D9	32	CABLE ASSY., SPEEDOMETER	F2	45
BEARING, RADIAL BALL, 17X42X12	D15	38		D9	32	CABLE COMP., CHOKE	F5	48
BEARING, RADIAL BALL, 6003	D7	30	BOLT, FLANGE, 8X16	D2	35	CABLE COMP., CLUTCH	F5	48
BEARING, RADIAL BALL, 6005UU	F15	58		D9	32	CABLE COMP., FR. BRAKE	F5	48
BEARING, RADIAL BALL, 6201U	D16	39	BOLT, FLANGE, 8X20	D12	35	CABLE COMP., THROTTLE	F5	48
BEARING, RADIAL BALL, 6203	D16	39		F14	57	CABLE, BATTERY EARTH	G16	75
BEARING, RADIAL BALL, 6204	D16	39	BOLT, FLANGE, 8X35	D6	29	CABLE, STARTER MAGNETIC	G16	75
BEARING, RADIAL BALL, 6301U	F13	56		D13	36	CABLE, STARTER MOTOR	G16	75
BEARING, RADIAL BALL, 6302U	F15	58	BOLT, FLANGE, 8X85	D9	32	CABLE, STRAP	F1	44
BEARING, ROLLER, 30X58X17	D14	37		D13	36	CAMSHAFT COMP.	D3	26
BODY COMP., BYSTARTER	E3	42	BOLT, FLANGE, 8X16	G2	61	CAM, FR. BRAKE	F12	55
BODY COMP., FRAME	H2	77		G2	66	CAM, RR. BRAKE	F14	57
BOLT-WASHER, 5X20	H1	76	BOLT, FLANGE, 8X20	G2	66	CAP ASSY., NOISE SUPPRESSOR	H1	76
BOLT A, BRAKE STOPPER	F9	52		F7	50	CAP COMP., FUEL FILLER	G1	60
BOLT A, BRAKE STOPPER ARM	G11	70	BOLT, FLANGE, 8X35	F8	51	CAP, 14MM	D9	32
BOLT A, FR. FORK	F11	54		G8	67	CAP, 32MM	D9	32
BOLT SET	D11	34	BOLT, FLANGE, 8X45	H2	77	CAP, LOCK NUT	F4	47
BOLT, BODY COVER SETTING	G7	66		H2	77	CAP, OIL FILTER ROTOR	D12	35
BOLT, CABLE ADJUST	F5	48	BOLT, FLANGE, 8X52	H2	77	CARBURETOR ASSY.	E3	42
BOLT, CYLINDER STUD, 8X140	D13	36	HELMET HOLDER SETTING	H2	77	CARRIER COMP., RR.	G2	61
BOLT, DRAIN PLUG, 12MM	D13	36	HEX., 5X25	G15	74	CASE COMP., INNER	F2	45
BOLT, DRIVE SPROCKET FIXING	D15	38	HEX., 6X12	G9	68	CASE COMP., UPPER	F2	45
BOLT, FLANGE SOCKET, 6X22	D2	25	BOLT, HEX., 6X20	E1	40	CASE SUB ASSY., AIR CLEANER	G5	64
BOLT, FLANGE, 10X110	H2	77		G8	67	CASE, DRIVE CHAIN	G11	70
BOLT, FLANGE, 10X55	G7	66	BOLT, KNOCK, 5MM	D4	27	CASE, FUSE	G16	75
			L. CRANKCASE COVER	D1	24	CASE, LOWER	F2	45
			L. HANDLE LEVER PIVOT	F5	48	CASE, L. BOTTOM	F10	53
			SOCKET, 6MM	D8	31			
			SOCKET, 6X16	D10	33			

