

PART NAME INDEX

Part name	Address	Page Ref.	Part name	Address	Page Ref.	Part name	Address	Page Ref.
PLATE A2, FIXING .....	D15	38	RUBBER, MUFFLER MOUNTING .....	G7	66	SEAL, RUBBER .....	G14	4
PLATE COMP., GEARSHIFT DRUM STOPPER	E1	40	RUBBER, PILLION STEP .....	G9	68	SEAL, VALVE STEM .....	D3	1
PLATE SET, VALVE .....	E3	42	RUBBER, PROTECTOR .....	G7	68	SEAT ASSY., DOUBLE .....	G2	2
PLATE, BEARING HOLDER .....	D13	36	RUBBER, RR. COWL .....	G3	62	SEAT, VALVE SPRING .....	D3	10
PLATE, BEARING PUSH .....	D13	36	RUBBER, RR. FUEL TANK MOUNTING G1	G1	60	SET RING, 20MM .....	D15	38
PLATE, CLUTCH .....	D7	30	RUBBER, SEAT CUSHION .....	G2	61	SHAFT A, GEARSHIFT FORK .....	E1	40
PLATE, CLUTCH LIFTER .....	D7	30	RUBBER, SHOCK .....	G16	75	SHAFT B, GEARSHIFT FORK .....	E1	4
PLATE, CLUTCH PRESSURE .....	D7	30	RUBBER, SIDE COVER .....	G4	65	SHAFT, MAIN STAND PIVOT .....	G10	69
PLATE, FR. ENGINE HANGER .....	H2	77	RUBBER, SPEEDOMETER MOUNTING ..	F2	43	SHAFT, REDUCTION GEAR .....	D8	31
PLATE, KICK STOPPER .....	E2	41	RUBBER, STOPPER ARM .....	F14	57	SHAFT, ROCKER ARM .....	D3	4
PLATE, L. BEARING SETTING .....	D13	36	[ S ]			SHOE SET, BRAKE .....	F12	55
PLATE, MAIN STEP LOWER .....	G9	68	SCREEN SET, FUEL STRAINER .....	G1	60	SHUTTER SET, KEY .....	F7	50
PLATE, MAIN STEP SIDE .....	G9	68	SCREEN, OIL FILTER .....	D12	35	SLIDER, CHAIN .....	G11	2
PLATE, STOPPER .....	D2	25	SCREW-WASHER, 3X22 .....	F2	45	SOCKET COMP. .... POSITION LIGHT ..	F1	45
PLATE, TENSIONER SETTING .....	D4	27	SCREW-WASHER, 4X12 .....	F3	46	SPACER, CHANGE SWITCH .....	D13	36
PLATE, WIRE HARNESS GUIDE .....	F8	51	SCREW-WASHER, 5X12 .....	E4	43	SPANNER, 10X14 .....	H3	78
PLUG .....	F2	45	SCREW SET A .....	E3	42	SPANNER, 8X12 .....	H3	5
PLUG, BEARING PUSH .....	D13	36	SCREW SET B .....	E3	42	SPANNER, PIN .....	H3	2
PLUG, SPARK .....	D2	25	SCREW, OVAL, 5X12 .....	D12	35	SPINDLE COMP., GEARSHIFT .....	E1	40
PUMP ASSY., OIL .....	D12	35	SCREW, OVAL, 5X16 .....	F12	55	SPOKE SET .....	F15	58
[ R ]			SCREW, PAN, 4X10 .....	E3	42	SPOKE SET A, 10X159 .....	F16	59
RACE, STEERING BOTTOM CONE .....	F8	51	SCREW, PAN, 4X12 .....	E4	43		F13	56
RACE, STEERING TOP BALL .....	F8	51	SCREW, PAN, 4X12 .....	G14	73			12
RACE, STEERING TOP CONE .....	F8	51	SCREW, PAN, 4X8 .....	E3	42			13
RATCHET, STARTER .....	E2	41	SCREW, PAN, 5X11.5 .....	G3	62	SPRING A, BRAKE ROD .....	G8	67
RECEIVER, CLUTCH CABLE .....	D6	29	SCREW, PAN, 5X12 .....	G3	62	SPRING G, MAIN STAND .....	G10	9
RECTIFIER ASSY., REGULATE .....	H1	76	SCREW, PAN, 5X13 .....	F1	44	SPRING SET, BRAKE PEDAL .....	G8	67
RECTIFIER ASSY., SILICON .....	H1	76	SCREW, PAN, 5X15 .....	F1	44	SPRING, BEARING PUSH .....	D13	36
REFLECTOR, REFLEX .....	G13	72	SCREW, PAN, 5X15.3 .....	G3	62	SPRING, BRAKE SHOE .....	F12	55
RELAY COMP., WINKER .....	H1	76	SCREW, PAN, 5X20 .....	F5	48	SPRING, CLUTCH .....	D7	30
RETAINER, VALVE SPRING .....	D3	26	SCREW, PAN, 5X28 .....	F5	48	SPRING, CLUTCH LEVER .....	D6	29
RIM, FR. WHEEL .....	F13	56	SCREW, PAN, 5X35 .....	F5	48	SPRING, COMPRESSION COIL .....	E3	42
RIM, RR. WHEEL .....	F15	58	SCREW, PAN, 5X45 .....	F6	49	SPRING, DRUM STOPPER .....	E1	40
RING SET, PISTON .....	D14	37	SCREW, PAN, 6X6 .....	D4	27	SPRING, FR. BRAKE ARM RETURN ..	F12	55
RING, BACK UP .....	F10	53	SCREW, SIDE STAND PIVOT .....	G10	69	SPRING, FR. FORK .....	F10	53
RING, OIL SEAL STOPPER .....	F11	54	SCREW, SPECIAL, 6X24 .....	G4	63	SPRING, GEARSHIFT RETURN .....	E1	40
RING, PISTON .....	F10	53	SCREW, SPECIAL, 6X8 .....	G14	73	SPRING, KICK RETURN .....	E2	41
ROD COMP., RR. BRAKE .....	G8	67	SCREW, STEERING HANDLE WEIGHT ..	F7	50	SPRING, KICK STARTER .....	G8	67
ROD, CLUTCH LIFTER .....	D7	30	SCREW, TAPET ADJUSTING .....	D3	26	SPRING, LOCK SETTING .....	G4	63
ROD, STOP SWITCH .....	G8	67	SCREW, TAPPING, 2.9X12 .....	F2	45	SPRING, OIL THROUGH .....	D12	35
ROLLER, 3X8.5 .....	E1	40	SCREW, TAPPING, 2.9X13 .....	G14	73	SPRING, RATCHET .....	E2	41
ROTOR, OIL FILTER .....	D12	35	SCREW, TAPPING, 2.9X8 .....	F2	45	SPRING, REBOUND .....	F10	53
ROTOR, OIL PUMP INNER .....	D12	35	SCREW, TAPPING, 3X16 .....	F7	50	SPRING, SIDE STAND .....	G10	69
ROTOR, OIL PUMP OUTER .....	D12	35	SCREW, TAPPING, 4X10 .....	G5	64	SPRING, STOP SWITCH .....	G8	67
RUBBER A, KICK STARTER .....	G8	67	SCREW, TAPPING, 4X12 .....	F3	46	SPRING, VALVE INNER .....	D3	26
RUBBER A, SEAT SETTING .....	G2	61	SCREW, TAPPING, 4X20 .....	G3	62	SPRING, VALVE OUTER .....	D3	26
RUBBER A, STAND STOPPER .....	G2	61	SCREW, TAPPING, 4X8 .....	D12	35	SPROCKET COMP., FINAL DRIVEN ..	F15	58
RUBBER B, SEAT SETTING .....	G16	75	SCREW, TAPPING, 4.2X14 .....	F2	45	SPROCKET, CAM .....	D4	27
RUBBER B, SHOCK .....	G16	75	SCREW, TAPPING, 5X25 .....	G5	64	SPROCKET, DRIVE .....	D15	38
RUBBER, BATTERY BOX .....	G8	67	SCREW, TRIP METER KNOB, 2X6 .....	F3	46	STAND COMP., MAIN .....	G10	69
RUBBER, CHANGE PEDAL .....	H2	77	SEAL SET, FR. FORK .....	F10	53	STATOR COMP. ....	D10	33
RUBBER, FUEL TANK STOPPER .....	D2	25	SEAL, AIR CLEANER .....	G5	64	STAY, BOTTOM BRIDGE .....	F8	51
RUBBER, INSERT .....	D5	28	SEAL, DUST .....	F11	54	STAY, HEADLIGHT .....	F1	44
RUBBER, MAIN STEP .....	G9	68				STAY, RR. WINKER .....	G13	72
RUBBER, MOUNTING .....	D1	24				STAY, WIRE .....	E3	42
						STEM SUB ASSY., STEERING .....	F8	51

