

**ILLUSTRATION MANAGEMENT NUMBER (IDENTIFICATION)
FOR '17 COTA 4RT PARTS LIST**

ENGINE GRUP	ILLUSTRATION NUMBER	FRAME GRUP	NÚMERO DE ILUSTRACIÓN
Cylinder head	E-1	Cable / Switch	F-1
Camshaft / Valve	E-2	Front brake master cylinder	F-2
Camchain / Tensioner	E-3	Clutch master cylinder	F-3
Cylinder	E-4	Steering handle pipe / Top bridge / Head light	F-4 (ED/2ED)
RH. Crankcase cover	E-5	Steering handle pipe / Top bridge	F-4 (3ED/4ED)
Clutch	E-6	Steering stem	F-5
Oil pump	E-7	Front fender	F-6
Water pump	E-8	Front fork (Tech)	F-7 (ED/3ED)
LH. Crankcase cover	E-9	Front fork (Showa)	F-7 (2ED/4ED)
Generator	E-10	Front brake caliper	F-8 (ED/3ED)
Crankcase	E-11	Front brake caliper	F-8 (2ED/4ED)
Crankshaft / Piston	E-12	Front wheel	F-9 (ED/3ED)
Transmission	E-13	Front wheel	F-9 (2ED/4ED)
Gearshift drum	E-14	Rear brake caliper	F-10
Kick starter spindle	E-15	Rear brake master cylinder	F-11
Throttle body / Injector	E-16	Rear wheel	F-12
		Fuel tank / Fuel pump	F-13 (ED/2ED)
		Fuel tank / Fuel pump	F-13 (3ED/4ED)
		Rear fender	F-14
		Air cleaner	F-15
		Exhaust muffler	F-16
		Pedal / Kick starter arm	F-17
		Stand / Step	F-18
		Swingarm	F-19
		Rear cushion (Oile)	F-20 (ED/3ED)
		Rear cushion (Showa)	F-20 (2ED/4ED)
		Wire harness	F-21
		Radiator	F-22
		Frame body	F-23
		Emblem / Stripe	F-24 (ED/3ED)
		Emblem / Stripe	F-24 (2ED/4ED)