

CONTENTS OF 2020 COTA 4RT PARTS LIST

INSTRUCTIONS FOR USE OF PARTS LIST			9
ENGINE GROUP			
E-1	Cylinder head	6	
E-2	Camshaft / Valve.....	8	
E-3	Camchain / Tensioner.....	9	
E-4	Cylinder	10	
E-5	RH. Crankcase cover.....	11	
E-6	Clutch	12	
E-7	Oil pump	13	
E-8	Water pump	14	
E-9	LH. Crankcase cover	15	
E-10	Generator.....	16	
E-11	Crankcase.....	17	
E-12	Crankshaft / Piston.....	19	
E-13	Transmission.....	20	
E-14	Gearshift drum.....	21	
E-15	Kick starter spindle.....	22	
E-16	Throttle body / Injector	23	
FRAME GROUP			
F-1	Cable / Switch	24	
F-2	Front brake master cylinder.....	25	
F-3	Clutch master cylinder.....	26	
F-4 (ED/2ED)	Steering handle pipe / Top bridge / Head light.....	27	
F-4 (3ED/4ED)	Steering handle pipe / Top bridge	29	
F-5	Steering stem	30	
F-6	Front fender	31	
F-7 (ED/3ED)	Front fork (Tech).....	32	
F-7 (2ED/4ED)	Front fork (Showa)	33	
F-8 (ED/3ED)	Front brake caliper.....	34	
F-8 (2ED/4ED)	Front brake caliper.....	35	
F-9 (ED/3ED)	Front wheel.....	36	
F-9 (2ED/4ED)	Front wheel.....	37	
F-10	Rear brake caliper	38	
F-11	Rear brake master cylinder	39	
F-12	Rear wheel.....	40	
F-13 (ED/2ED)	Fuel tank / Fuel pump.....	42	
F-13 (3ED/4ED)	Fuel tank / Fuel pump.....	43	
F-14	Rear fender.....	44	
F-15	Air cleaner.....	45	
F-16	Exhaust muffler.....	46	
F-17	Pedal / Kick starter arm.....	47	
F-18 (ED/3ED)	Stand / Step	48	
F-18 (2ED/4ED)	Stand / Step	49	
F-19	Swingarm.....	50	
F-20 (ED/3ED)	Rear cushion (R16V)	52	
F-20 (2ED/4ED)	Rear cushion (Showa).....	53	
F-21	Wire harness.....	54	
F-22	Radiator	56	
F-23	Frame body	57	
F-24 (ED/3ED)	Emblem / Stripe.....	58	
F-24 (2ED/4ED)	Emblem / Stripe.....	59	
F-25	Optional parts	60	
F-26	Optional parts (Replica).....	61	