

## ILLUSTRATION MANAGEMENT NUMBER (IDENTIFICATION)

### FOR '20 COTA 301RR PARTS LIST

ENGINE GROUP	ILLUSTRATION NUMBER	FRAME GROUP	ILLUSTRATION NUMBER
Cylinder head .....	E-01	Cable / Switch .....	F-01
Camshaft / Valve .....	E-02	Front brake master cylinder .....	F-02
Camchain / Tensioner .....	E-03	Clutch master cylinder .....	F-03
Cylinder .....	E-04	Steering handle pipe / Top bridge / Head light .....	F-04 (2ED)
RH. Crankcase cover .....	E-05	Steering handle pipe / Top bridge / .....	F-04 (4ED)
Clutch .....	E-06	Steering stem .....	F-05
Oil pump .....	E-07	Front fender .....	F-06
Water pump .....	E-08	Front fork (Tech) .....	F-07
LH. Crankcase cover .....	E-09	Front brake caliper .....	F-08
Generator .....	E-10	Front wheel .....	F-09
Crankcase .....	E-11	Rear brake caliper .....	F-10
Crankshaft / Piston .....	E-12	Rear brake master cylinder .....	F-11
Transmission .....	E-13	Rear wheel .....	F-12
Gearshift drum .....	E-14	Fuel tank / Fuel pump .....	F-13 (2ED)
Kick starter spindle .....	E-15	Rear fender .....	F-14
Throttle body / Injector .....	E-16	Air cleaner .....	F-15
		Exhaust muffler .....	F-16
		Pedal / Kick starter arm .....	F-17
		Stand / Step .....	F-18
		Swingarm .....	F-19
		Rear cushion (Showa) .....	F-20
		Wire harness .....	F-21
		Radiator .....	F-22
		Frame body .....	F-23
		Emblem / Stripe .....	F-24
		Optional parts (Replica) .....	F-25
		Optional parts .....	F-26