


F - 9

Front Wheel



Service item	F.R.T.	No.	Part Number	Description	Q'ty	Notes
RIM, RR. WHEEL	2.2	1	42701-086-910	RIM, RR. WHEEL	1	
TUBE, TIRE	0.8	2	22517-2501700	TUBE. TIRE (2.25/2.50-17)	1	
TIRE, FR. WHEEL		3	44301-GN5-960	AXLE, FR. WHEEL	1	
AXLE, FR. WHEEL	0.2	4	44311-GN5-900	COLLAR, FR. WHEEL SIDE	1	
HUB, FR. WHEEL	2.5	5	44601-GN5-960FMS	HUB FR. WHEEL NH 310	1	
BEARING, RADIAL BALL, 6301U	0.4	6	1110-159S	SPOKE SET 22517	1	
(ADD 0.1 FOR EACH)		8	44620-400- 000	COLLAR, FR. AXLE DISTANCE	1	
		9	44710-GBG-881	TIRE, FR. WHEEL (2.25-274 PR)	1	
		10	42713-GN8-F00	FLAP, FR TUBE (17)	1	
		11	90755-229-003	OIL SEAL, 21x37x7	1	
		12	94101-12000-0S	NUT, CASTEL, 12MM	1	
		13	94101-12000	WASHER, PLAIN, 12MM	1	
		14	94201-30250	PIN, SPLIT, 3.0X25	1	
		15	HB 6301	BEARING, RADIAL BALL, 6301U	1	

15.01.2001