Maintenance Schedule

Perform the Pre-Ride Inspection in the Owner's Manual at each scheduled maintenance period.

I: Inspect and clean, Adjust, Lubricate, or Replace if necessary.

C: Clean, R: Replace, A: Adjust, L: Lubricate

The following items require some mechanical knowledge. Certain items (particularly those marked *and **) may require more technical information and tools. Consult their authorized Honda dealer.

	Frequency	Whichever	⇔ Odometer Reading (Note 1)								
		Comes	×1,000km	1	6	12	18	24	30	36	Refer to
		First	X1,000mi	0.6	4	8	12	16	20	24	page
Item		❖	Months		6	12	18	24	30	36	
*	Fuel Line					ı		ı		l	Note 6
*	Throttle Operation					1		ı		1	Note 6
*	Carburetor Choke					ı		1		1	Note 6
	Air Cleaner	Note 2					R			R	3–5
	Crankcase Breather	Note 3			С	С	С	С	С	С	Note 6
	Spark Plug				Ī	R	ı	R	ļ	R	Note 6
*	Valve Clearance			ı	ı	ı		ı		ı	3–5
	Engine Oil			R		R		R		R	Note 6
	Engine Oil Filter			R		R		R		R	Note 6
*	Carburetor Synchronization					1		ı		ı	3–8
*.	Carburetor Idle speed			1	1	I	ı	1	ı	ı	Note 6
	Radiator Coolant	Note 4				ı				R	Note 6
*	Cooling System					ı		Ī		1	Note 6
*	Secondary Air Supply System	Note 5				I		Ī		ı	Note 6
	Drive Chain			Every 1,000km (600mi) I, L						3–10	
	Drive Chain Slider				Ĭ	1		ı		ı	Note 6
	Battery				I	1	1	1	1	1	Note 6
	Brake Fluid	Note 4			ī	Ī	R	Ī	ı	R	3–13
	Brake Pad Wear				1	1	1	ı	Ī	1	3–12
	Brake System			ī		I		ı		I	3–13
*	Brake Light Switch					ı		1		ı	Note 6
*	Headlight Aim					I		ı		i _	3–14
	Clutch System					1		1		ı	Note 6
	Clutch Fluid	Note 4			1	1	R	I	ı	R	Note 6
	Side Stand					ı		1		ı	Note 6
*	Suspension					ı		ı		1	Note 6
*	Nuts, Bolts, Fasteners			ı		1		1		I	1–14
**	Wheels/Tires					ı		ı		l I	Note 6
**	Steering Head Bearing			ı		ı		1		l	Note 6

- * Should be serviced by your authorized Honda dealer, unless the owner has the proper tools and service data and is mechanically qualified.
- ** In the interest of safety, we recommended these items be serviced only by your authorized Honda dealer.

Notes: 1. At higher odometer readings, repeat at the frequency interval established here.

- 2. Service more frequently when riding in unusually wet or dusty areas.
- 3. Service more frequently when riding in rain or at full throttle.
- 4. Replace every 2 years, or at indicated odometer interval, whichever cames first. Replacement requires mechanical skill.
- 5. Switzerland and Austria type only.
- 6. Refer to Common Service Manual.