

6. FUEL SYSTEM (Programmed Fuel Injection)

COMPONENT LOCATION	6-2	IDLE AIR CONTROL (IAC) THERMAL VALVE	6-56
SERVICE INFORMATION	6-3	IDLE AIR CONTROL (IAC) VALVE	6-57
TROUBLESHOOTING	6-6	IAC VALVE SYNCHRONIZATION	6-61
SYSTEM LOCATION	6-7	MAP SENSOR	6-64
SYSTEM DIAGRAM	6-8	IAT SENSOR	6-65
PGM-FI SELF-DIAGNOSIS INFORMATION	6-9	ECT SENSOR	6-65
MIL CODE INDEX	6-13	CMP SENSOR	6-66
MIL TROUBLESHOOTING	6-15	BANK ANGLE SENSOR	6-67
FUEL LINE INSPECTION	6-31	ENGINE STOP RELAY	6-68
FUEL PUMP UNIT	6-33	ENGINE CONTROL MODULE (ECM)	6-69
FUEL CUT-OFF RELAY	6-35	PAIR CONTROL SOLENOID VALVE	6-71
FUEL TANK	6-36	EVAP PURGE CONTROL SOLENOID VALVE (CALIFORNIA TYPE ONLY)	6-72
AIR CLEANER HOUSING	6-40	INTAKE AIR DUCT	6-73
SECONDARY INJECTOR	6-43	EGCV (Exhaust Gas Control Valve)	6-76
THROTTLE BODY	6-47	EGCV SERVOMOTOR	6-78
PRIMARY INJECTOR	6-54		