

INSTALLATION

Place front fork in bottom bridge
Install stopper ring into fork pipe groove
Install handlebars (12.3)
Tighten top bridge

Torque : 0.9-1.3Kg-m

Tighten bottom bridge bolt

Torque : 4.5-5.5 kg-m

Install fork bolt

Torque : 1.5-3.0 kg-m

Install front fender
Install brake pipe

* Place bolts in both sides of brake pipe and after deciding on correct position, tighten bolts

Install brake caliper (14.6)
Install front wheel (12.9)
Adjust front fork air pressure (2.7)

STEERING STEM

Removal

Remove steering stem nut, washer
Loosen top bridge bolt and remove top bridge

Standard tools
Extension bar

Lock nut wrench (30×32mm) 07716-0020500

Remove front wheel (12.6)
Remove front forks (12.10)
Remove centre lower fairing (15.3)

