

Requisite Service

- Lower center fairing removal/installation (page 2-9)

Procedure		Q'ty	Remarks
<p>Removal Order Wind shield:</p> <p>(1) Flange screw (2) Washer screw (3) Rear view mirror inner cover (4) Bolt (5) Rear view mirror (6) Mirror plate</p> <p>(7) Seat rubber</p> <p>(8) Wind shield</p>		<p>2 2 2 4 2 2</p> <p>2</p> <p>1</p>	<p>Installation is in the reverse order of removal.</p> <p>NOTE</p> <ul style="list-style-type: none"> • Install the right plate with the marked side facing in and the left plate with the marked side facing out, and each arrow marks pointing forward and up. <p>NOTE</p> <ul style="list-style-type: none"> • Install the right rubber seat with the "R" mark facing in and the left rubber seat with the "L" mark facing out. <p>NOTE</p> <ul style="list-style-type: none"> • Remove from the fairing stay bosses while carefully spreading open the rear end of the upper fairing. <p>CAUTION</p> <ul style="list-style-type: none"> • Be careful not to damage or scratch the shield. <p>NOTE</p> <ul style="list-style-type: none"> • Before installation, make sure the four seat rubbers onto the fairing stay bosses. • At installation, align the front end with the grooves in the upper fairing.
<p>Upper fairing:</p> <p>(9) Headlight socket (10) Turn signal connector (11) Position light connector (12) Socket bolt (13) Socket bolt/grommet (14) Upper fairing</p>		<p>2 2 1 2 2/2 1</p>	<p>Release the wire from the clips on the reverse side of the left air intake duct.</p> <p>NOTE</p> <ul style="list-style-type: none"> • At installation, align holes in the headlight with the mounting bosses of the fairing stay.