PART NAME INDEX

J 1

Part name	Address	Page	Ref.
[A]			
AID KIT, FIRST	H5	86	1
ARMATURE	D12	39	7
ARM ASSY., KICK STARTER	G11	76	1
ARM SET, L. PIVOT	F15	64	16
ARM SET, R. PIVOT	F15	64	8
ARM, FR. BRAKE	G1	66	15
ARM, RR. BRAKE	G3	68	7
ARM, VALVE ROCKER	D5	32	5
AXLE, FR. WHEEL	G1	66	6
[B]			
BACK PLATE, NUMBER PLATE STAY	G6	71	12
BAG, SERVICE BOOK	G4	69	9
BAG, TOOL, 160MM	H5	86	11
BALL, STEEL,	F16	65	39
			40
BAND COMP., BATTERY	H1	82	5
BAND, AIR CLEANER CONNECTING TUBE	G7	72	17
BAND, HANDLE BRACKET	F4	53	18
BAND, HARNESS	H3	84	21
BAND, L. COVER DUCT	H4	85	2
BAND, SPARE TIRE BRACKET	H11	92	7
BAND, TOOL	G4	69	11
BAR COMP., SIDE STAND	G11	76	5
BAR, L. PILLION STEP	F11	60	4
BAR, R. PILLION STEP	F11	60	3
BAR, SEAT LOCK	G4	69	14
BASE COMP., L. FR. WINKER	G13	78	5
BASE COMP., L. WINKER	G14	79	4
BASE COMP., RR.	G16	81	5
BASE COMP., R. WINKER	G14	79	2
BASE, L. RR. WINKER	G13	78	11
BASE, R. FR. WINKER	G13	78	2
BASE, R. RR. WINKER	G13	78	8
BASE, TAILLIGHT	G15	80	2
BATTERY	H1	82	1
BATTERY ASSY.	H1	82	1
BEARING, NEEDLE, 17X25X18	D15	42	19
BEARING, RADIAL BALL SPECIAL, 6007	E2	45	10
BEARING, RADIAL BALL SPECIAL, 6203	E1	44	11
BEARING, RADIAL BALL, 6004UU	D16	43	9
BEARING, RADIAL BALL, 6201	D16	43	14
	E1	44	17
BEARING, RADIAL BALL, 6201U	G1	66	21
BEARING, RADIAL BALL, 6202	E1	44	18
BEARING, RADIAL BALL, 6205Z	E2	45	9
BEARING, RADIAL BALL, 6301	D16	43	15
BEARING, RADIAL BALL, 6901U	D15	42	18
BELT, DRIVE	D15	42	6
BODY COMP., FRAME	H4	85	3
BODY COMP., HIGH TENSION TERMINAL	H3	84	28
BOLT-WASHER, 5X12	D12	39	11
BOLT-WASHER, 6X12	F11	60	9
	G5	70	11
	G6	71	7
BOLT-WASHER, 6X20	D1	28	10
	F4	53	30
	F11	60	10
	H8	89	14
	H9	90	16
BOLT-WASHER, 6X30	G8	73	8
	G9	74	10
BOLT-WASHER, 6X40	G7	72	12
BOLT-WASHER, 8X16	G4	69	12
BOLT A, STUD, 7X181	D9	36	6
BOLT B, STUD, 7X186	E1	44	9
BOLT, ADJUSTING	F1	50	6
BOLT, DRAIN PLUG, 12MM	D9	36	10
BOLT, FLANGE, 10X20	F13	62	19
BOLT, FLANGE, 10X210	H4	85	10
BOLT, FLANGE, 10X238	H4	85	11
BOLT, FLANGE, 10X35	G12	77	5
BOLT, FLANGE, 10X40	G10	75	7
BOLT, FLANGE, 10X45	F6	55	13
BOLT, FLANGE, 5X16	H8	89	12
BOLT, FLANGE, 6X10	F7	56	3
	F9	58	20
	G10	75	11
BOLT, FLANGE, 6X115	D9	36	16
BOLT, FLANGE, 6X12	F9	58	19
	F10	59	27
	G9	74	13
	G10	75	8
	H1	82	6
	H4	85	19
BOLT, FLANGE, 6X14	D2	29	9
BOLT, FLANGE, 6X16	D4	31	23
	D10	37	9
			10
	E1	44	15
	G4	69	13
	H3	84	22
BOLT, FLANGE, 6X18	H3	84	23
			24
BOLT, FLANGE, 6X20	H11	92	12
BOLT, FLANGE, 6X22	D7	34	10
	D9	36	13
	D10	37	11
	G11	76	13
BOLT, FLANGE, 6X25	D1	28	12
	D3	30	21
BOLT, FLANGE, 6X30	D4	31	24
	D16	43	12
	G3	68	10
BOLT, FLANGE, 6X32	G2	67	27
BOLT, FLANGE, 6X35	D12	39	13
	D13	40	9
BOLT, FLANGE, 6X40	D16	43	13
BOLT, FLANGE, 6X55	D9	36	14
BOLT, FLANGE, 6X75	D13	40	10
BOLT, FLANGE, 6X80	D9	36	15
BOLT, FLANGE, 6X90	D4	31	22
BOLT, FLANGE, 8X12	E1	44	16
BOLT, FLANGE, 8X16	F12	61	14
	F13	62	18
	H11	92	10
BOLT, FLANGE, 8X35	G10	75	7
BOLT, FLANGE, 8X50	H11	92	11
BOLT, FLANGE, 8X55	F16	65	38
BOLT, HEAD COVER	D2	29	5
BOLT, HEX., 6X14	G6	71	15
BOLT, HEX., 6X30	D11	38	5
BOLT, HEX., 8X32	F16	65	31
	G12	77	4
BOLT, HEX., 8X45	H10	91	8
BOLT, INNER COVER	F9	58	13
BOLT, KNOCK, 5MM	D5	32	16
	D10	37	6
BOLT, MAIN STAND SPRING	E1	44	8
BOLT, SIDE STAND PIVOT	G11	76	8
BOLT, STUD, 6X16	D3	30	19
BOLT, STUD, 8X22	G1	66	17
	G3	68	9
BOSS, DRIVE FACE	D14	41	2
BOX ASSY., INNER	H9	90	2
BOX B SET, INNER	H8	89	10
BOX B, INNER	H8	89	3
BOX LOWER, BATTERY	H1	82	4
BOX SET, INNER	H9	90	7
BOX UPPER, BATTERY	H1	82	3
BOX, LUGGAGE	G4	69	10
BRACKET COMP., FR.	D12	39	6
BRACKET SET, SPARE TIRA	H11	92	13
BRACKET, HANDLE	F4	53	17
BRACKET, SPARE TIRE	H11	92	4
BULB	F2	51	1
			2
BULB, HEADLIGHT	F1	50	4
BULB, TAILLIGHT	G15	80	6
	G16	81	7
BULB, WINKER	G13	78	13
	G14	79	5
	G16	81	6
BUSH, ENGINE HANGER RUBBER	D9	36	2
	E1	44	1
BUSH, FR. CUSHION UNDER	F15	64	14
BUSH, KICK SPINDLE	D14	41	11
BUSH, PIVOT ARM	F15	64	7
BUSH, RR. CUSHION RUBBER	G12	77	2
BUSH, RR. CUSHION UNDER RUBBER	E1	44	3
BUSH, RUBBER	F16	65	25
	G12	77	2
[C]			
CABLE COMP., CHOKE	F3	52	2
CABLE COMP., FR. BRAKE	F3	52	11
CABLE COMP., RR. BRAKE	F3	52	10
CABLE COMP., SPEEDOMETER	F2	51	13
CABLE SET, THROTTLE	F3	52	1

5