PART NAME INDEX

J 5

Part name	Address	Page	Ref.
SEAL, AIR CLEANER COVER	G7	72	2
SEAL, DUST, 20X32X5	G1	66	20
SEAL, HIGH TENSION TERMINAL	H3	84	27
SEAL, INNER BOX	H9	90	5
SEAL, INNER BOX LID B	H8	89	4
SEAL, OUTER INNER	H9	90	6
SEAL, SHROUD	D1	28	4
SEAL, SUB AIR CLEANER	G6	71	3
SEAL, VALVE STEM	D5	32	1
SEAT COMP., DOUBLE	G4	69	3
SEAT, VALVE SPRING	D5	32	13
SET, FR. NUMBER PLATE	F10	59	24
SHAFT, DRIVE	D16	43	4
SHAFT, EX. ROCKER ARM	D5	32	7
SHAFT, IN. ROCKER ARM	D5	32	6
SHAFT, MAIN STAND	G11	76	3
SHOE SET, BRAKE	G1	66	2
	G3	68	2
SHROUD, EX.	D1	28	5
SHROUD, IN.	D1	28	2
SOCKET COMP.	F2	51	10
SOCKET COMP., HEADLIGHT	F1	50	3
SOCKET COMP., TAILLIGHT	G15	80	5
SPANNER, 10X12	H5	86	10
SPEEDOMETER ASSY.	F2	51	3
SPINDLE COMP., KICK STARTER	D14	41	10
SPLASH GUARD, RR. FRAME	H4	85	17
SPRING ASSY., MAIN STAND	G11	76	14
SPRING, BRAKE ARM RETURN	G1	66	16
SPRING, BRUSH	D12	39	3
SPRING, CARBON BRUSH	D12	39	3
SPRING, CLUTCH	D15	42	3
SPRING, DRIVEN FACE	D15	42	11
SPRING, FR. BRAKE SHOE	G2	67	28
	G3	68	17
SPRING, KICK DRIVEN GEAR	D14	41	8
SPRING, KICK RETURN	D14	41	13
SPRING, LOCK KEY SETTING	F13	62	1
	H8	89	1
	H9	90	1
SPRING, OIL FILTER SCREEN	E1	44	7
SPRING, PARKING LEVER RETURN	F4	53	22
SPRING, RR. BRAKE ARM	G3	68	8
SPRING, RR. BRAKE SHOE	G3	68	17
SPRING, SEAT CATCH	G4	69	8
SPRING, SIDE STAND	G11	76	6
SPRING, STEP RETURN	H10	91	5
SPRING, VALVE INNER	D5	32	11
SPRING, VALVE OUTER	D5	32	10
SPROCKET, CAM	D5	32	4
SPROCKET, TIMING	E2	45	6
STAND COMP., MAIN	G11	76	2
STAND SET, SIDE	G11	76	7
STATOR COMP.	D10	37	3
STAY B, SEAT LOCK CABLE	F13	62	5
STAY COMP., L. FR. COVER	F6	55	4
STAY COMP., R. FR. COVER	F6	55	3
STAY SET, RR. NUMBER PLATE	G6	71	14
STAY, AIR SUCTION VALVE	G9	74	7
STAY, FR. NUMBER PLATE	F10	59	23
STAY, IGNITION COIL	H2	83	5
STAY, RR. NUMBER PLATE	G6	71	11
STAY, SEAT LOCK CABLE	F13	62	4
STEP ASSY., SARI	H10	91	1
STEP COMP., SARI	H10	91	7
STOPPER, RUBBER	D13	40	6
	F10	59	22
	H4	85	6
STOPPER, STEP RUBBER	H10	91	6
SUB CORD, IGNITION COIL	H2	83	6
SUB HARNESS	D12	39	9
SUSPENSION, STARTER RELAY	H3	84	18
SUSPENSION, WINKER RELAY	H3	84	16
SWITCH ASSY., COMBINATION & LOCK	H2	83	12
SWITCH ASSY., FR. STOP	F3	52	9
SWITCH UNIT, DIMMER	F3	52	6
SWITCH UNIT, HORN	F3	52	7
SWITCH UNIT, LIGHTING	F3	52	4
SWITCH UNIT, STARTING	F3	52	5
SWITCH UNIT, WINKER	F3	52	8
[T]			
TAILLIGHT ASSY.	G15	80	1
TANK COMP., FUEL	G5	70	3
TENSIONER COMP., CAM CHAIN	D7	34	2
TIRE	G1	66	4
	G3	68	5
	H11	92	3
TOOL SET	H5	86	2
TRAY COMP., BATTERY	F8	57	1
TUBE COMP., FUEL	G5	70	6
TUBE COMP., VACUUM	G5	70	7
TUBE SET, TUFF UP	G1	66	1
	G3	68	1
	H11	92	1
TUBE, 3.5X160	G8	73	11
TUBE, 3.5X280	E3	46	21
TUBE, AIR CLEANER CONNECTING	G7	72	8
TUBE, AIR CLEANER DRAIN	G7	72	7
TUBE, AIR SUCTION VALVE	G8	73	4
	G9	74	4
			6
TUBE, BATTERY BREATHER	H1	82	2
TUBE, BREATHER	D2	29	1
TUBE, MISSION BREATHER	D16	43	1
TUBE, VINYL, 8X12X210	G7	72	4
[V]			
VALVE ASSY., AIR SUCTION	G8	73	3
	G9	74	3
VALVE COMP., FLOAT	E3	46	15
VALVE SET, THROTTLE	E3	46	7
VALVE, EX.	D5	32	9
VALVE, IN.	D5	32	8
[W]			
WASHER	G11	76	9
WASHER O-RING KIT A	E5	48	2
WASHER O-RING KIT B	E6	49	2
WASHER, 10MM	D10	37	7
WASHER, 16MM	G3	68	13
WASHER, 7.2X16X2.5	D3	30	15
WASHER, DRAIN PLUG, 12MM	D9	36	11
	E6	49	2
WASHER, KICK SPINDLE	D14	41	16
WASHER, LOCK NUT	F16	65	34
WASHER, LOCK, 6MM	F1	50	7
WASHER, PLAIN, 10MM	F6	55	12
WASHER, PLAIN, 12MM	G11	76	9
WASHER, PLAIN, 6MM	F10	59	26
	F12	61	11
	G10	75	6
WASHER, PLAIN, 8MM	H10	91	10
WASHER, REGULATOR SETTING	G8	73	6
	G9	74	8
WASHER, SEALING, 8MM	E1	44	10
	E6	49	2
WASHER, SPECIAL, 12MM	D14	41	15
WASHER, SPECIAL, 8MM	F16	65	33
WASHER, SPEEDOMETER GEAR	G1	66	10
WASHER, SPRING, 4MM	G4	69	16
WASHER, STEERING HEAD DUST SEAL	F16	65	29
WASHER, THRUST, 10MM	D14	41	14
WASHER, THRUST, 6MM	D15	42	15
WEIGHT SET, CLUTCH	D15	42	4
WHEEL SUB ASSY., FR.	G1	66	9
WHEEL SUB ASSY., RR.	G3	68	3
WINKER ASSY., L. FR.	G13	78	4
WINKER ASSY., L. RR.	G13	78	10
WINKER ASSY., R. FR.	G13	78	1
WINKER ASSY., R. RR.	G13	78	7
WRENCH, BOX	H5	86	7
WRENCH, EYE, 14MM	H5	86	12
WRENCH, EYE, 19MM	H5	86	8
WRENCH, PLUG	H5	86	6
[Y]			
YOKE	D12	39	8