PART NAME INDEX

J 4

Part name	Address	Page	Ref.
[R]			
RACE, STEERING BALL	F7	50	4
RACE, STEERING BOTTOM CONE	F7	50	6
RACE, STEERING TOP CONE	F7	50	5
RATCHET, KICK STARTER	E3	42	2
RECTIFIER ASSY., REGULATOR	G13	72	5
RECTIFIER ASSY., SILICON	G13	72	6
RELAY COMP., WINKER	G13	72	9
RETAINER, STARTER SPRING	E3	42	7
RETAINER, VALVE SPRING	D3	26	17
RIM COMP., HEADLIGHT	F1	44	2
RIM, FR. WHEEL	F11	54	6
RIM, RR. WHEEL	F13	56	8
RING	D11	34	4
RING SET, PISTON	D15	38	2
RING, BACK UP	F9	52	5
RING, OIL SEAL STOPPER	F9	52	22
RING, PISTON	F9	52	9
ROD COMP., RR. BRAKE	G4	63	9
ROD, CLUTCH LIFTER	D7	30	7
ROD, PUSH	D3	26	10
ROLLER, 4X10	E2	41	18
ROTOR COMP., OIL FILTER	D12	35	6
ROTOR, OIL PUMP INNER	D12	35	4
ROTOR, OIL PUMP OUTER	D12	35	5
RUBBER A, SHOCK	G12	71	12
RUBBER B, SEAT SETTING	F15	58	2
RUBBER B, SHOCK	G12	71	13
RUBBER, AIR CLEANER CASE MOUNTING	G1	60	8
RUBBER, BATTERY BOX	G12	71	17
RUBBER, BATTERY CUSHION	G12	71	4
RUBBER, CHANGE PEDAL	G4	63	18
RUBBER, CUSHION	D9	32	7
RUBBER, FR. FENDER MOUNTING	G11	70	5
RUBBER, KICK STARTER	G4	63	5
RUBBER, NUMBER PLATE BRACKET CUSHION	G9	68	11
RUBBER, PILLION STEP	G5	64	3
RUBBER, RR. COVER MOUNTING	D9	32	4
RUBBER, STAND STOPPER	G6	65	3
RUBBER, STEP	G5	64	2
RUBBER, STOPPER ARM	F12	55	7
[S]			
SCREEN SET, FUEL STRAINER	F14	57	3
SCREEN, OIL FILTER	D13	36	8
SCREW-WASHER, 4X10	E4	43	19
			20
SCREW-WASHER, 4X16	E4	43	21
SCREW-WASHER, 5X14	G9	68	15
SCREW-WASHER, 5X16	G15	74	4
SCREW-WASHER, 5X8	G1	60	19
SCREW-WASHER, 6X12	G1	60	18
SCREW-WASHER, SPECIAL, 4X12	F2	45	15
SCREW SET A	E4	43	5
SCREW SET B	E4	43	8
SCREW, BEAM ADJUST	F1	44	3
SCREW, FLAT, 4X12	D12	35	12
SCREW, FLAT, 5X12	D12	35	13
SCREW, FLAT, 6X30	D12	35	14
SCREW, OVAL, 5X16	F10	53	11
SCREW, OVAL, 6X35	F6	49	9
SCREW, PAN, 4X10	F2	45	17
SCREW, PAN, 4X30	F2	45	18
SCREW, PAN, 5X13	G11	70	9
SCREW, PAN, 5X20	F4	47	22
SCREW, PAN, 5X28	F4	47	23
SCREW, PAN, 5X35	F4	47	24
SCREW, PAN, 5X45	F5	48	25
SCREW, SIDE STAND PIVOT	G6	65	6
SCREW, SPECIAL, 6X13	G2	61	13
SCREW, TAPPET ADJUSTING	D3	26	22
SCREW, TAPPING, 4X12	F2	45	19
SCREW, TAPPING, 4X16	G10	69	10
SCREW, TAPPING, 4X30	G11	70	8
SCREW, TAPPING, 5X16	G1	60	20
SCREW, U-LOCK FLAT, 6X12	F7	50	15
SEAL SET, FR. FORK	F9	52	11
SEAL, AIR CLEANER CASE	G1	60	7
SEAL, TANK STORAGE	G1	60	14
SEAL, VALVE STEM	D3	26	1
SEAT ASSY., DOUBLE	F15	58	1
SEAT, VALVE SPRING	D3	26	18
SEAT, VALVE SPRING INNER	D3	26	19
SET RING, 20MM	D16	39	24
	E3	42	14
SHAFT, CAM FOLLOWER	D3	26	5
SHAFT, CAM GEAR	D3	26	6
SHAFT, GEARSHIFT FORK	E2	41	4
SHAFT, MAIN STAND PIVOT	G6	65	4
SHAFT, REDUCTION	D8	31	3
SHAFT, ROCKER ARM	D3	26	12
SHAFT, STARTER GEAR	D8	31	4
SHOE SET, BRAKE	F10	53	16
	F12	55	1
SLIDER, DRIVE CHAIN	G7	66	6
SOCKET COMP.	F2	45	10
SOCKET COMP., HEADLIGHT	F1	44	9
SOCKET COMP., POSITION LIGHT	F1	44	11
SPANNER, 10X12	G15	74	5
SPANNER, 14X17	G15	74	6
SPINDLE COMP., GEARSHIFT	E2	41	9
SPINDLE, KICK STARTER	E3	42	3
SPOKE SET	F11	54	12
			13
	F13	56	19
			20
SPRING A, BRAKE ROD	G4	63	19
SPRING A, SIDE STAND	G6	65	9
SPRING B, MAIN STAND	G6	65	8
SPRING, BEAM ADJUSTING	F1	44	4
SPRING, BEARING PUSH	D13	36	7
SPRING, BRAKE PEDAL	G4	63	11
SPRING, BRAKE SHOE	F10	53	17
	F12	55	9
SPRING, CAMSHAFT	D3	26	7
SPRING, CLUTCH	D7	30	13
SPRING, CLUTCH LEVER	D6	29	5
SPRING, FR. BRAKE ARM RETURN	F10	53	8
SPRING, FR. FORK	F9	52	2
SPRING, GEARSHIFT PLATE	E2	41	11
SPRING, GEARSHIFT RETURN	E2	41	12
SPRING, KICK STARTER	E3	42	5
SPRING, KICK STARTER RATCHET	E3	42	4
SPRING, KICK STARTER STOPPER	G4	63	6
SPRING, OIL FILTER SCREEN	D13	36	9
SPRING, OIL THROUGH	D12	35	9
SPRING, REBOUND	F9	52	4
SPRING, SHIFT DRUM STOPPER	E2	41	8
SPRING, STOP SWITCH	G4	63	8
SPRING, VALVE INNER	D3	26	16
SPRING, VALVE OUTER	D3	26	15
SPROCKET COMP., FINAL DRIVEN	F13	56	1
SPROCKET, DRIVE	D16	39	16
STAND COMP., MAIN	G6	65	1
STATOR COMP.	D10	33	4
STAY ASSY., BATTERY	G12	71	15
STAY COMP., AIR SUCTION VALVE	G2	61	7
STAY COMP., BATTERY	G12	71	1
STAY, HORN	F7	50	12
STEM SUB ASSY., STEERING	F7	50	9
STOPPER COMP., GEARSHIFT DRUM	E2	41	7
STRIPE, L. FUEL TANK	H1	76	2
STRIPE, L. SIDE COVER	H1	76	6
STRIPE, R. FUEL TANK	H1	76	1
STRIPE, R. SIDE COVER	H1	76	5
SUSPENSION, WINKER RELAY	G13	72	10
SWINGARM ASSY., RR.	G7	66	4
SWITCH ASSY., CHANGE	D13	36	13
SWITCH ASSY., COMBINATION	F6	49	2
SWITCH ASSY., FR. STOP	F4	47	7
SWITCH ASSY., RR. STOP	G4	63	7
SWITCH ASSY., STARTER MAGNETIC	G12	71	11
SWITCH COMP., FR. LEVER	F4	47	6
SWITCH COMP., STARTER	F4	47	4
SWITCH COMP., WINKER	F4	47	5
[T]			
TAILLIGHT UNIT	G11	70	1
TANK SUB ASSY., FUEL	F14	57	8
TERMINAL SET, BRUSH	D11	34	2
THREAD COMP., STEERING HEAD TOP	F7	50	10
THROUGH, OIL	D12	35	8
TIRE, FR.	F11	54	7
TIRE, RR.	F13	56	9
TOP SET	E4	43	4
TUBE	E4	43	18
TUBE A, AIR SUCTION VALVE	G2	61	8
TUBE B, AIR SUCTION VALVE	G2	61	9
TUBE B, BREATHER	G1	60	12
TUBE C, AIR SUCTION VALVE	G2	61	10
TUBE, AIR CLEANER CONNECTING	G1	60	9