

• FUEL LEVEL CHECK AND REPLENISHMENT

Before riding, check the fuel level in the fuel tank and add fuel if necessary. The fuel fill cap (1) is removed by twisting it counterclockwise. Automotive petrol with a pump octane number ($\frac{R+M}{2}$) of 86 or higher, or a research octane number of 91 or higher may be used.

FOR AUSTRALIA ONLY:

Use unleaded fuel with a research octane number of 91 or higher.

If "knocking" or "pinging" occurs, try a different brand of petrol or a higher octane grade.

▲ WARNING

- * *Petrol is extremely flammable and is explosive under certain conditions. Refuel in a well-ventilated area with the engine stopped. Do not smoke or allow flames or sparks in the area where petrol is stored or where the fuel tank is refueled.*
- * *Do not overfill (there should be no fuel in the filler neck). Failure to fill the tank properly may cause fuel to leak through the fuel tank breather tube.*



CAUTION:

- * *Remove the fuel fill cap by slowly turning it by hand.*

