













## UP LVL

You can select the shift pedal load level for activating the Quick Shifter when upshifting.

- 1 Select the "UP LVL" using the **SEL**  (up) or **SEL**  (down) button, and press the **MODE** button.
  - u Press and hold the **SEL**  (up) or **SEL**  (down) button to move the menu quickly.

12:34		SETTING	0 mph
SPORTS KIT	SUSPENSION M3	UP	
EXIT		DOWN	
FUNCTION QUICKSHIFTER		UP LVL	
LAP TIME	SUSPENSION A1	DOWN LVL	
DISPLAY	SUSPENSION A2		

- 2 Select one of the three levels using the **SEL**  (up) or **SEL**  (down) button.
  - u Press and hold the **SEL**  (up) or **SEL**  (down) button to move the menu quickly.
  - u Available setting range:  
1 (light operation) to 3 (heavy operation)

12:34		SETTING	0 mph
SPORTS KIT	SUSPENSION M3		
EXIT		1	
FUNCTION QUICKSHIFTER		2	
LAP TIME	SUSPENSION A1	3	
DISPLAY	SUSPENSION A2		

- 3 Press the **MODE** button. The "UP LVL" setting is set, and then the display returns to the upper level hierarchy.